


SENSORS PLATFORM USER MANUAL



INFRASENSING

Copyright:

Copyright © 2024 InfraSensing BV All rights reserved.

Reproduction without permission is prohibited.

Software:

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Trademarks:

ServersCheck and InfraSensing are registered trademarks of InfraSensing BV. All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer:

Information in this document is subject to change without notice and does not represent a commitment on the part of InfraSensing BV.

Revision # 101 - Sensors Platform

InfraSensing BV provides this document “as is,” without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. InfraSensing BV reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

InfraSensing BV has made this document to the best of its abilities. However InfraSensing BV assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

For UL compliant use we refer to the UL compliancy guide available on http://manuals.infrasensing.com/UL_Compliancy_Guide_v1.pdf

Warranty:

For the warranty on this product please visit <https://infrasensing.com/>

OPENING BASE UNIT, ADDON, EXPANSION HUB, SENSOR OR ANY OTHER HARDWARE VOIDS THE WARRANTY

Certifications:



The InfraSensing sensors are FCC (Class A) & CE (Class B) certified. Certificates can be downloaded from <https://infrasensing.com/sensors>

Commissioning Requirements

Testing and Verification: Before deploying any InfraSensing sensors into production, it is the responsibility of the customer to rigorously test each sensor during the commissioning phase. This is to ascertain and confirm the proper and accurate operation of the sensors, to ensure the integrity of data communication pathways, and to verify that alert mechanisms are configured and functioning correctly.

Gas Sensor Bump Testing: For all gas sensors provided by InfraSensing, a mandatory bump test shall be conducted during the commissioning phase. Bump testing is a quick check to confirm the sensor's responsiveness. It involves exposing the sensor to a known concentration of test gas and verifying the sensor's response.

Annual Review: In accordance with applicable code requirements, gas sensors shall be subjected to periodic bump testing at a minimum frequency of once annually. The customer is responsible for scheduling and ensuring this testing takes place and for maintaining accurate records of each test conducted.

Safety precautions

Caution

For safety reasons, the Base Units (base units), add-ons, expansion hubs and sensor probes may never be moved, disconnected, connected fully or partially covered while operating. Disconnect any power supply before performing installation or maintenance work.

Danger

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH FOR POWER SENSORS OR SENSORS IN ELECTRICAL ENVIRONMENTS

Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices. In the USA, see NFPA 70E.

Only qualified electrical workers should install electrical equipment like our power sensors. Such work should be performed only after reading this entire set of instructions. NEVER install if something is not clear.

NEVER work alone.

Before performing visual inspections, tests, or maintenance on this equipment, disconnect all sources of electric power. Assume that all circuits are live until they have been completely de-energized, tested, and tagged.

Turn off all power supplying the power sensors and the equipment (such as base units) in which it is installed before working on it.

Always use a properly rated voltage sensing device to confirm that all power is off.

The successful operation of this equipment depends upon proper handling, installation, and operation. Neglecting fundamental installation requirements may lead to personal injury as well as damage to electrical equipment or other property.

NEVER bypass external fusing.

Before performing testing on any equipment in which the power sensors are installed, disconnect all input and output wires to the power meter. High voltage testing may damage electronic components contained in the electronics.

The power sensors should be installed in a suitable electrical enclosure.

Failure to follow the above instructions may result in damage of the equipment, serious personal injury or death.

Table of Contents

1	InfraSensing Sensors Overview.....	11
1.1	Unboxing video of the InfraSensing sensors.....	11
1.2	Base Unit Overview	11
1.3	Base Unit Hardware.....	13
1.4	Base Unit's LED table	14
1.5	OLED display subscripts.....	15
1.6	Dimensions of the sensor gateway	15
1.7	Rack mounting.....	16
1.8	DIN rail mounting	16
1.9	Magnetic mounting.....	17
1.10	Base Unit interface overview	17
1.11	Configuring the Base Unit to the network.....	18
1.12	Base Unit discovery tool.....	18
1.13	Set your PC in the same network segment as the Base Unit	19
1.14	Connecting to the Base Unit via the default IP	21
1.15	Updating the firmware of the Base Unit	24
1.16	Configuring the Base Unit's access security	25
2	Base Unit Security Feature.....	26
2.1	Username and Password configuration	26
2.2	Firewall settings.....	27
2.3	Enabling and Disabling Web Server	28
3	Base Unit features and configuration	30
3.1	Int. ping.....	30
3.2	Configuring the Fahrenheit / Celsius readings.....	31
3.3	ICMP server	32
3.4	Sensor polling/refresh time	32
3.5	Configuring internal clock of the Base Unit	33
3.6	Setting threshold values in the Base Unit for alerting	37
4	Base Unit alerting feature.....	38
4.1	Email alerting.....	38
4.2	Email alerts using the ADDON-LTE	39
4.2.1	Gmail as e-mail server (https://mail.google.com).....	40
4.2.2	Outlook mail as e-mail server (https://outlook.live.com).....	44
4.2.3	Using InfraSensing premium e-mail (https://my.InfraSensing.com).....	46
4.3	Slack channel integration via e-mail alerts.....	46
4.4	Tunneling an SSL connection	48
4.5	Mail service like AuthSMTP.com	53
4.6	SMS alerting from Base Unit.....	54
4.6.1	SMS alerts via ADDON-LTE.....	54

	4.6.2	SMS alerts via my.infrasensing premium credits	56
	4.6.3	Sending SMS alerts and JSON Push data using the Microservice feature	58
	4.7	Voice call alerts	61
	4.8	Retest before alarm	63
	4.9	Maintenance Mode	64
	4.10	Fault Sensor	65
5		History	66
	5.1	Alert history	66
	5.2	Fault history	67
6		Configuring the Base Unit for SNMP	68
	6.1	SNMP get requests	69
	6.2	SNMP traps	74
	6.3	JSON (PULL)	76
	6.4	JSON (PUSH) with ADDON-LTE	78
	6.5	JSON (PUSH) with ADDON-LTE - Adding Webhook Endpoint	79
	6.6	XML output	81
	6.7	ModBus TCP / RTU	81
7		Sensor calibration	82
	7.1	Reference Sensors	83
	7.2	Tolerance level	83
	7.3	Threshold change and additional calibration functions	84
8		Factory resetting of Base Unit	86
	8.1	Base Units v1 and v2	86
	8.2	Base Unit v3 and v4	87
	8.3	Base Unit v5	88
9		Add-Ons for the Base Unit	89
	9.1	Wifi Add-On	89
	9.1.1	Features.....	90
	9.1.2	View of the Wifi Add-On connected to the Base Unit.....	90
	9.1.3	Hardware interface	91
	9.1.4	Getting started	92
	9.1.5	How to access the Graphical User Interface (GUI).....	93
	9.1.6	Username and password settings	95
	9.1.7	Configuration modes	96
	9.2	Satellite Communication Add-On (ADDON-SATELLITE)	101
	9.3	Industrial PoE+ Injectors +24 or -48v (ADDON-POE-24 / ADDON-POE-48)	102
	9.4	LTE/2G/3G Communication Add-On (ADDON-LTE)	103
	9.4.1	GUI of the ADDON-LTE.....	104
	9.4.2	ADDON-LTE modes.....	106
	9.4.3	Setting up data connection	108

	9.4.4	SIM section	111
	9.4.5	Email section	111
	9.4.6	GPS section.....	112
	9.4.7	Inserting the SIM card into the LTE Add-On.....	112
10		InfraSensing sensor probes	115
	10.1	External sensor probes	115
	10.2	General instructions	115
11		THERMAL IMAGING SENSORS.....	117
	11.1	Thermal Imaging Sensor (THIMG-XX)	117
	11.1.1	Installation of Thermal Image	117
	11.1.2	Adding Zones to the Thermal Imaging Sensor Camera	118
	11.1.3	Delete Zones from the Thermal Imaging Sensor Camera.....	118
	11.2	Thermal Image Sensor (THIMG-SC).....	119
	11.3	Industrial Infrared Spot Sensor (THIMG-STD-IRSPOT).....	119
12		Gas Sensors.....	120
	12.1	Ammonia (NH3) Gas Sensor (GAS-NH3).....	120
	12.2	Carbon Dioxide (CO2-NDIR) Gas Sensor (GAS-CO2-NDIR)	120
	12.3	Carbon Monoxide (CO) Gas Sensor (GAS-CO)	121
	12.4	Chlorine (CL2) Gas Sensor (GAS-CL2)	121
	12.5	Ethylene (C2H4) Gas Sensor (GAS-C2H4)	122
	12.6	Ethylene Oxide (ETO) Gas Sensor (GAS-ETO)	122
	12.7	Formaldehyde (CH2O) Gas Sensor (GAS-CH2O)	123
	12.8	Hydrogen (H2) Gas Sensor (GAS-H2-2)	123
	12.9	Hydrogen Chloride (HCL) Gas Sensor (GAS-HCL)	124
	12.10	Hydrogen Fluoride (HF) Gas Sensor (GAS-HF).....	124
	12.11	Hydrogen Sulfide (H2S) Gas Sensor (GAS-H2S).....	125
	12.12	Methane (CH4) Gas Sensor (GAS-CH4).....	125
	12.13	Methyl Mercaptan (CH3SH) Gas Sensor (GAS-CH3SH)	126
	12.14	Nitric Oxide (NO) Gas Sensor (GAS-NO)	126
	12.15	Nitrogen Dioxide (NO2) Gas Sensor (GAS-NO2).....	127
	12.16	Oxygen (O2) Gas Sensor (GAS-O2).....	127
	12.17	Ozone (O3) Gas Sensor (GAS-O3)	128
	12.18	Phosphine (PH3) Gas Sensor (GAS-PH3)	128
	12.19	Sulfur Dioxide (SO2) Gas Sensor (GAS-SO2)	129
	12.20	Sulfur Hexafluoride (SF6) Gas Sensor (GAS-SF6)	129
	12.21	Refrigerant A1 (R-404A, R-22, and R-410A) Gas Sensor (GAS-A1)	130
	12.22	Refrigerant A2L (R-32, R-1234YF, R-1234ZE and R-454B) Gas Sensor (GAS-A2L) 130	
	12.23	Refrigerant A3 (R-290) Gas Sensor (GAS-A3)	131
	12.24	Refrigerant (R-134a) Gas Sensor (GAS-R134a).....	131

	12.25	Gas Sensor Bump Test.....	132
13		Environmental Sensors	133
	13.1	Temperature Sensor (ENV-TEMP)	133
	13.2	Temperature & Humidity Sensor (ENV-THUM).....	133
	13.3	Magnetic Surface Temperature Sensor (ENV-TEMP-MAGNETIC)	134
	13.4	Digital Sound and Noise level Sensor(dbA) (ENV-NOISE)	134
	13.5	Atmospheric Corrosion Sensor (ENV-CORROSION).....	135
	13.6	Differential Air Pressure and Temperature Sensor (ENV-AIRPRESSURE).....	135
	13.7	Linear Heat Detection Sensor (ENV-LHD)	136
	13.8	Optical Dust Sensor Probe (ENV-DUST)	136
	13.9	Particle Sensor (ENV-PARTICLE)	137
	13.10	Water Leak Sensor (ENV-WLEAK-COMBO5M)	137
	13.11	Optical Oil & Hydrocarbon Leak Sensor (ENV-LEAK-OPTICAL)	138
	13.12	Stainless Steel Temperature Probe (ENV-TSTAIN)	138
	13.13	Extreme Low Temperature Sensor (ENV-TULTRA)	139
	13.14	Industrial Surface Temperature Sensor (ENV-TSURFACE)	139
	13.15	IP rated sensor assembly (leak, industrial probes, etc.).....	140
	13.16	Water Spot Detection Sensor (monitors a specific spot) (ENV-WSPOT)	142
	13.17	View of the Airflow Sensor (ENV-AIRFLW)	143
14		Daisy Chain	144
	14.1	Daisy Chain Temperature Sensor (DAISY-TEMP).....	144
	14.2	Daisy Chain Temperature and Humidity Sensor (DAISY-THUM).....	144
	14.3	Daisy Chain Infrared Spot Sensor (DAISY-THIMG-IRSPOT).....	145
	14.4	Daisy Chain Temperature Magnet Sensor (DAISY-TEMP-MAGNET)	145
	14.5	ISO 17025 Calibrated Cylindrical Daisy Chained Temperature & Humidity Sensor (DAISY-THUM-C)	146
	14.6	Daisy Chain Start (DAISY-STARTER)	146
	14.6.1	Connecting Daisy Chain Sensor	147
	14.7	Daisy Booster	153
15		Power Sensors	154
	15.1	View of DC Voltage Sensor Sensor (12-80V) (PWR-DC-VOLT)	154
	15.2	View of Current Sensor (PWR-AC-CUR)	154
	15.3	View of AC power failure (PWR-AC-FAIL)	156
	15.3.1	Main sensor unit (PWR-BAT-STRING).....	157
	15.4	Power Quality Sensor (PWR-AC-QUAL)	158
	15.4.1	Initial set up for the power quality sensor using BASE-XX.....	159
	15.4.2	Initial set up for the power quality sensor using SD card .ini file	160
	15.4.3	Ground (Earthing) Monitoring Sensor (PWR-GROUND)	161
	15.5	IP68 Ultrasonic Fuel Level Sensor (PWR-FUEL)	163
	15.5.1	Features	163

	15.5.2	Maximum Tank Depths	163
	15.5.3	Dimensions	163
	15.5.4	Mounting and installation.....	164
	15.5.5	Tips and example installations.....	165
16		Industrial sensor	168
	16.1	Industrial 0-10V (IND-0-10V)	168
	16.2	Industrial 4-20mA (IND-4-20mA)	168
	16.3	The IO Sensor Probe – 16 Dry Contacts IN & 4 OUT (IND-IO)	169
	16.4	General description	169
	16.5	Applications	169
	16.6	Terminal description.....	169
	16.7	Basic wiring diagram	170
	16.8	Base Unit IO sensor probe interface	173
	16.9	Wiring configuration and settings (anti tampering).....	174
	16.10	Output triggering	177
17		Security Sensors.....	178
	17.1	General description	178
	17.2	Door Sensor (SEC-DOOR)	178
	17.3	Motion Sensor (SEC-MOTION).....	179
	17.4	Smoke Sensor (SEC-SMOKE).....	181
	17.4.1	Installation guide for Security Smoke Sensor	182
	17.5	Sound Sensor (SEC-SOUND)	183
	17.6	Digital Luminosity Sensor (LUX) (SEC-LUX)	183
	17.7	Shock / Vibration Sensor (SEC-SHOCK)	184
	17.8	Tilt Sensor (SEC-TILT)	184
18		The Sensor Hub (EXP-8HUB)	185
	18.1	General description	185
	18.2	Probe restrictions	186
	18.3	Connecting the SensorHub to the Base Unit.....	186
	18.4	Terminal connections	187
	18.5	Basic wiring.....	188
	18.6	Basic wiring diagram	189
	18.7	SensorHub web interface	191
19		LoRa Wireless Hub and Node	192
	19.1	Connecting and Pairing	193
20		Automatic & remote control of equipment	197
	20.1	Triggering outputs through the web interface.....	198
	20.2	Wiring for a control output.....	199
	20.3	Geomapping sensors.....	200
21		Power rating	201

Note:

For technical support kindly visit <https://infrasensing.com/support>

In June 2018 we did rebrand our sensor platform from ServersCheck to **InfraSensing**. This document may still include references to ServersCheck in graphics and images while the InfraSensing name is now being used

1 InfraSensing Sensors Overview

1.1 Unboxing video of the InfraSensing sensors


We invite you to watch following unboxing video before unpacking, installing and configuring your InfraSensing sensors:

<https://infrasensing.com/sensors/>



1.2 Base Unit Overview

The Base Unit is the heart of the InfraSensing sensors. This base unit is where all the smart logic resides: from connection to monitoring, reporting and alerting.



The Base Unit is connected to the network via a standard network cable over a 10/100Mbps network. It supports PoE too. This allows for powering the sensors without having to rely on external power adapters. If you don't have a PoE network then a power adapter is optionally available.


Note: If a power adapter (BASE-PWR) and POE is plugged into the gateway to supply power at the same time the gateway will automatically switch to the power adapter and use POE as backup, Also the gateway will not shutdown or restart if either one is unplugged.

In the following sections of this user manual, we are going to describe in detail the configuration and operation of the base unit.


It is recommended to verify the calibration of the temperature probe in your environment and if an offset is noticed, to recalibrate the sensor as explained in **section 6** of this document.

The maximum tested length between a PoE switch and the Base Unit is 330ft or 100meters (Using Cat6 shielded cables). Actuals may vary depending on cable quality, switch and environmental factors.

1.3 Base Unit Hardware



- A. Ethernet/PoE Port – for network and PoE connection via RJ45
- B. Status LED
 - a. Yellow (Network) – Stable = Network established, No Light = No Network
 - b. Green (Sensor) – Stable = External Probe detected, No Light = No External Probe
- C. Int. Temp. – Base Unit's built in Temperature Sensor
- D. OLED Screen
 - a. OLED displays a rolling banner that has the following information:
 - Base Unit IP Address
 - Date
 - Time
 - Internal Temperature of Base Unit
- E. Sensor Probe Ports – where sensor probes connect via RJ45
- F. Reset Button
 - a. By pressing the Reset button it will reboot the Base Unit
 - b. By pressing the reset button and releasing it after 10 seconds, it will force the Base Unit to load the Default Setting. To cancel press and hold the button again for 1-3 seconds. OLED sequence is shown below.



- G. Power Adapter DC Jack – where optional Power Adaptor connects to provide power when PoE is unavailable.

1.4 Base Unit's LED table



The following table details the different led indication combinations. Each combination allows you to visually get the nature of the state/issue

Yellow LED (Network/Online)	Green LED (Sensor)	Description
Flashing (fast, ~1/10 sec)	On	Updating firmware after reboot. Reboot time is about 5 seconds before Base Unit is ready.
Flashing (slow, ~1 sec)	Any	Can't sync with NTP (time) server
On	Any	Synchronized with NTP (time) server
Any	Flashing	Can't communicate with external sensor probe
Any	On	Connected with external sensor probe

Normal Power on Reset, No New Firmware Uploaded

Power ON state: Yellow & Green LED are ON for 2 seconds and start flashing

Run state: Yellow & Green LED are both flashing
Green LED is ON if able to connect with external sensor probe
Yellow LED is ON if able to sync with NTP (time) server

Reboot, New Firmware Uploaded

Power ON state: Yellow & Green LEDs are ON for 1 second and Yellow LED starts flashing

Updating firmware state: takes around 20 seconds
Green LED stays ON
Yellow LED will flash very fast (about 1/10 seconds)

Ready state: Yellow & Green LED are both flashing
Green LED is ON if able to connect with external sensor probe
Yellow LED is ON if able to sync with NTP (time) server


Note : Various options will appear including Start, Webserver, Reboot, and Load Default, depending on the duration of pressing the reset button.

1.5 OLED display subscripts



The OLED display gives one a quick view of the values the Base Unit reading. The reference for the order of the subscript numbering is completely dependent on how the web page is showing it.

1.6 Dimensions of the sensor gateway




Measurement unit in millimeter (mm)

1.7 Rack mounting


The Base Unit and most of our sensors are 0U devices that can be easily and securely mounted in a rack using standard rack mount screws with a head of at least 0.65cm / 0.26 inch. Although one screw is sufficient to hold the whole equipment in place, a second one improves stability.

Typically, the sensors are mounted at the rear of the rack where ample place is available so that it doesn't use any space reserved for server and other network rack mounted equipment.




1.8 DIN rail mounting

The base unit has DIN mounting provisions that can be easily attached on DIN mounting clips using standard screws with a head of at least 0.6cm / 0.24 inch. The clips are then mounted on DIN rails as shown on the image below.



1.9 Magnetic mounting

As our base unit, add-ons, expansion hubs, and most sensors feature a metal steel enclosure, the devices can also be mounted using simple magnets.



1.10 Base Unit interface overview

Connect to the InfraSensing Base Unit using your browser and on the IP address defined in the next section.

Image of the left side of the main page.




(1) This is the Home Button which will bring you to the sensor information page whenever it is clicked.


(4) The sensors will be shown on this portion of the page

(5) Additional options will appear on this area depending on the sensor connected (Wireless Hub, Thermal Image, etc.)

Image of the right side of the main page.



(2) The Menu Button, when clicked will show the options on the image below.



(3) Edit button to configure the thresholds and alerting features for each of your sensor

1.11 Configuring the Base Unit to the network

The Base Unit can have 2 types of IPv4 addresses: Fixed or Dynamic (using DHCP). By

default, the gateway will try to get an IP address via DHCP to connect to your network. If this fails, then the default IP address from factory of the Base Unit is **192.168.11.160**

To change the IP address to a different fixed one, proceed as follows.


We highly recommend not using DCHP but instead to use fixed IP addresses.

Make sure the Base Unit is plugged with a network cable into the network.

1.12 Base Unit discovery tool

If you have connected multiple gateways and wanted to check their IP/MAC address you can use our tool to immediately show all the Base Unit connected within your network. All you have to do is run the software, which can be downloaded, from <https://infrasensing.com/support/downloads.asp>


Works with Windows(Discoverer.exe) and Mac OS(Discoverer.jar).




1.13 Set your PC in the same network segment as the Base Unit

The steps below apply to a Windows 7 system. For other systems (Windows, Mac, Linux) steps are similar. You may skip the instructions entirely, provided your gateway received an IP address from your DHCP server (you can check via our Network Discovery Tool) or your network segment is already the same as the gateways default IP and that the IP 192.168.11.160 is not being used/leased.

Go to Network Panel > Network & Sharing Center




Click on **Local Area Connection** and then click on **Properties**. In the new window select **Internet Protocol Version 4** and click on the **Properties** button.



Now you need to set in the Properties window your PC in the same IP range as the sensor. Remember the current settings of your PC before changing any value!

We recommend setting it to 192.168.11.159 as shown below. When done, click on the **OK** button.

You can now plug your Base Unit directly to your PC



Note: the gateway needs a Power Adapter so you can directly connect it via the PC's Ethernet port unless the port supports PoE.


1.14 Connecting to the Base Unit via the default IP

Once you have completed **Section 2.9**, Open your browser and surf to <http://192.168.11.160>
A connection will be made to the web server on board of the Base Unit and you will be prompted for a username & password. Default username and password is: **admin / admin**



When logged in you will be shown the main screen of the Base Unit with the first sensor reading being the built-in temperature probe.

In the main window, click on the **Menu button** located on the upper right corner of the page. Then click on settings, and once the page loads click on **"Change IP"**



Settings & Info

Device information

Account name

admin

[Change Password](#)

Current System Date

13 Feb 2019

Current System Time

00:24:47

[Update Time](#)

Hardware Version

Release 5.1

Firmware Version

Release 8.00 (Feb 12 2019)

[Upgrade Firmware](#)

Mac Address

00:03:64:03:44:40

IP Address

192.168.11.103

[Change IP](#)

Node Status (online/used/max)

2/17/44

[Calibrate Sensors](#)

You can now change the Base Unit's IP address to any value you like: either to DHCP or to a fixed IP that would fit your local network. We will now set it to 10.0.0.36 with its default gateway to 10.0.0.1 respectively. As for the DNS server feel free to use any, in this set up, we will use 4.2.2.2 and 8.8.8.8. You can also see the MAC address of the gateway and set the Net BIOS Name.


Note: If you want to make a device accessible via DNS please make sure that the Net BIOS Name is 15 or more characters if not, then it will be appended with a blank space because of the padding process of Microsoft please see link. <https://technet.microsoft.com/en-us/library/cc958811.aspx>

Once the value has been changed, the Base Unit will reboot itself and will then be accessible through the newly defined IP.


Network Settings

Fixed IP	<input checked="" type="checkbox"/>
DHCP	<input type="checkbox"/>
ICMP Server	<input checked="" type="checkbox"/>
IP Address	10.0.0.36
Subnet Mask	255.255.255.0
Gateway	10.0.0.1
Primary DNS	4.2.2.2
Secondary DNS	8.8.8.8
Net BIOS Name	SENSORGATEWAY
Mac Address (HEX)	00:03:64:03:03:E8
<input type="button" value="Update"/> <input type="button" value="Reset"/>	

Now reset your system to its normal IP address. In our case we reset it to DHCP.



We will now check the Base Unit and connect to its new IP address by connecting to it using a browser.



As seen on the image above, We were able to access the gateway via its new IP address since our network segment is set at 10.0.0.X and we set our computer back to DHCP the gateway is now connected and can be accessed through our network.

1.15 Updating the firmware of the Base Unit

InfraSensing may release from time to time new firmware versions for its Base Units.

You can check your currently installed firmware version by going to your Base Unit, and then click on the menu option then settings.

Settings & Info

Device information

Account name	admin
	Change Password
Current System Date	14 Feb 2019
Current System Time	03:57:16
	Update Time
Hardware Version	Release 5.1
Firmware Version	Release 8.00 (Feb 12 2019)
	Upgrade Firmware
Mac Address	00:03:64:03:44:40
IP Address	192.168.11.104
	Change IP
Node Status (online/used/max)	3/43/44
	Calibrate Sensors

Go to <http://www.infrasensing.com/sensors/firmware.asp> to check for new firmware releases. Simply check on that page the latest firmware version available for your Base Unit

You must be on firmware version 8.5 or above before uploading the latest firmware.

Download the firmware to your PC and then go with your browser to the Base Unit you wish to upgrade.

Click on the **Upgrade Firmware** option and then click on the **Browse** button to locate the downloaded firmware file. Only then click on the **Upload** button.


Your Base Unit will now start loading the new firmware. Your Base Unit will be available on <http://192.168.11.160> (Default) or via the IP address shown on its OLED after the firmware update has been completed

Note: Should the upgrade fail and should the Base Unit be unresponsive then perform a factory reset as described in section 8.

1.16 Configuring the Base Unit's access security

The Base Units can be username and password secured. Default factory values are **admin/admin**

To change the values, click on the **Settings** menu option



Click on "Change Password" and enter the new username and password

Settings & Info

Device information

Account name

admin

Change Password

Current System Date

14 Feb 2019

Current System Time

01:02:05

Update Time

Hardware Version

Release 5.1

Firmware Version

Release 8.00 (Feb 12 2019)

Upgrade Firmware

Mac Address

00:03:64:03:44:40

IP Address

192.168.11.104

Change IP

Node Status (online/used/max)


3/43/44

Calibrate Sensors

2 Base Unit Security Feature

2.1 Username and Password configuration

Every time you access your base unit, a pop-up message will appear prompting you to enter your username and password.



Sign in to 192.168.11.230:80
Your password will be sent unencrypted.

User Name

Password

☐ Remember this password

Cancel Sign In

You can configure or edit the username and password for your device by accessing the settings of your base unit and click on the change password.



Settings & Info

Device information

Account name admin

Change Password

On this page, you can configure the username for your base unit and update your password. Please note that the password must be between 5 and 20 characters in length. Once you have updated it, simply click on the "Update" button.



User Account

Username admin

New Password *****

Retype Password

Update Reset

2.2 Firewall settings

Firewall can be accessed through your gateway's settings by clicking on the button on the upper right,



With this feature you may configure your gateway to allow access to specific IP/MAC or a range of IP/MAC addresses.

Firewall Settings

This firewall feature enables to disable access to the web interface, SNMP agent or Modbus TCP based on the IP address **AND** MAC address filters.

You can use wildcards (*) to allow multiple addresses from a same subnet to access the device..

Your IP: 192.168.11.45
Your MAC address: C0:56:27:39:6E:24

IP address #1	<input type="text" value="*.*.*.*"/>
IP address #2	<input type="text"/>
IP address #3	<input type="text"/>
IP address #4	<input type="text"/>
IP address #5	<input type="text"/>
MAC #1	<input type="text" value="*:*:*:*:*:"/>
MAC #2	<input type="text"/>
MAC #3	<input type="text"/>
MAC #4	<input type="text"/>
MAC #5	<input type="text"/>

Note that both fields cannot be left blank. The input “*.*.*.*” will allow all IP and as for allowing all MAC address we need to input “*:*:*:*:*:”, they are already typed in by default.

Note: MAC address letters should always be in upper case.


2.3 Enabling and Disabling Web Server

Web Server is one of the newest features included in the latest firmware version. Disabling the web server option restricts the ability to send commands or configure settings. To disable it, simply select "Disable" from the dropdown menu and click "Update".



The screenshot shows a web interface for configuring the 'Web Server'. On the left, the text 'Web Server' is displayed. To its right is a dropdown menu with two options: 'Disable' and '✓ Enable'. Below the dropdown are three buttons: an orange 'Update' button, a red 'Reboot' button, and a blue 'Legal Info' button.

Once you click on "Disable", a pop-up message will appear asking if you want to disable the web server. After you click "Ok" and then "Update", the web server is disabled. You will not be able to load the web server, send commands or configure it.




After you disable the web server, your base unit will automatically reboot, and you will see this reflected in your base unit's OLED.



After the base unit reboots, a message will appear to inform you that the Web server is Disabled.

Please note that a common mistake users make when unable to access the base unit is that the web server is turned off. To verify, reboot the base unit and check the OLED display for the message indicating that the web server is Disabled or off.

To enable it back, you will need to be near the device as you need to press the reset button 4 times within 2 seconds. This is an additional security measure added to the Web Server feature, as you will need to be physically present with the device to manually re-enable it.



After you enable the web server again, a message will appear on the Base Unit's OLED display indicating that the Web server is Enabled, and you may now access your web server again.




3 Base Unit features and configuration

3.1 Int. ping

Once you have updated to firmware 8.0 and above an internal ping check is added on our sensor list where in you can check the status of your connection to a specific URL or IP address in which a great example is trying to ping another gateway (BASE-XX).

How to set it up

1. Access your gateway and click on the “PING” option.



2. Make sure to click on “Enable Ping”




3. Input the URL / IP address you wanted you check and then click on UPDATE.




3.2 Configuring the Fahrenheit / Celsius readings

The default setup is readings in Celsius. However, through a simple switch, the sensor readings can be set to Fahrenheit. Simply connect to the Base Unit, go to the menu option and click on settings.



Change the value from Celsius to Fahrenheit under general settings.



3.3 ICMP server

The Internet Control Message Protocol (ICMP) is widely used for diagnostic purposes

Network Settings

Fixed IP	<input checked="" type="checkbox"/>
DHCP	<input type="checkbox"/>
ICMP Server	<input checked="" type="checkbox"/>

By Default your ICMP Server is enabled, you may disable it through your network settings page.

3.4 Sensor polling/refresh time

Can also be found under general settings, the unit dictates the time the gateway polls/gets the data from any of the sensors connected to it. Recommended setting is from 1-5 seconds.

General settings	
Device Name	SensorGateway
Device Location	Data Center
Sensor Polling	every 1
Temperature Unit	Celsius
OLED Screen	Enable
Repeat Alarm Time	every 5

3.5 Configuring internal clock of the Base Unit

To modify the internal clock, click on the menu option and then go to settings and then click on "Update Time". You can either set it manually or have it synchronized with a timeserver as shown in the picture below. Click on **Update** when done

SNTP Settings

Use SNTP Time Server ☒

Current Device Date & Time 14 Feb 2019 01:12:03

Update date time to 14 February 2019 1:10

IP Address SNTP Time Server us.pool.ntp.org

Time Zone +8 (configured)

SNTP Sync Frequency every 1

Update Reset

Following table provides a list of time zones in UTC offset per country.

Country	UTC time offset	Country	UTC time offset
A		M	
Afghanistan	+04	Macedonia *	+01
Albania *	+01	Madagascar	+03
Algeria	+01	Malawi	+02
Andorra *	+01	Malaysia	+08
Angola	+01	Maldives	+05
Antigua and Barbuda	-04	Mali	±00
Arg'entina	-03	Malta *	+01
'Ar'enia	'04	Marshall Islands	+12
Australia – 5 time zones		Mauritania	±00
Western Australia'08 Northern Territory +09		Mauritius	+04
South 'Australia * +09 Austr'alian C'apital		Mexico * – 3 time zones	
Territory * +10 New South Wale's * +10		The state o'Baja California –08 The states of	
Queens'a'+10 Tasmania * '10 Victoria * '+0 Lor'		Baja California Sur, Chihuahua, Nayarit,	
Howe Island'* +10 M'c'uraei Is'and +11		Sinaloa and Sonora –07 Most of Mexico –06	
Australian Overseas Territories – 6 time		Micronesia – 2 time zones	
Zones		The states of Chuuk and Yap +10 The states	
Heard Island and McDonald Islands +05		of Kosrae and Pohnpei +11	
Cocos (Keeling) Islands +06 Christmas Island		Moldova *	+02
+07 Ashmore and Cartier Islands +08 Coral		Monaco *	+01
Sea Islands +10 Norfolk Island +11		Mongolia * – 2 time zones	
Austria *	+01	Provinces of Khovd, Uvs, Bayan-Olgii +07	
Azerbaijan *	+04	Ulaanbaatar and most of the country +08	
B		Montenegro *	+01
Bahamas *	–'5	Morocco *	±00
Bahrain	+03	Mozambique	+02
Bangladesh	+06	Myanmar (Burma)	+06::
Barbados	–04	N	
Belarus	+03	Namibia	+01
Belgium *	+01	Nauru	+12
Belize	–06	Nepal	+05:45
Benin	+01	Netherlands *	+01
Bhutan	+06	Netherlands Overseas Territories – 1 time	

Bolivia	-04	zones	
Bosnia and Herzegovina *	+01	Aruba -04 Caribbean Netherlands -04	
Botswana	+02	Curaçao -04 Sint Maarten -04	
Brazil - 4 time zones		New Zealand *	+12
Acre and Southwestern Amazonas -05 Most		New-Zealand's Dependent Territories - 4	
part of the Amazonas State, Mato Grosso,		time zones	
Mato Grosso do Sul, Rondônia, Roraima -04		Niue -11 Cook Islands -10 Chatham Islands	
The Southeast, the South, the Northeast		+12:45 Tokelau +13	
Regions (except some islands), Goiás, Distrito		Nicaragua	-06
Federal, Tocantins, Pará, Amapá -03 Islands		Niger	+01
on the east coast of Brazil (Fernando de		Nigeria	+01
Noronha, Trindade, Martin Vaz, Atol das		North Korea	+09
Rocas, Saint Peter and Paul Rocks) -02		Norway *	+01
Brunei	+08	O	
Bulgaria *	+02	Oman	+04
Burkina Faso	±00	P	
Burundi	+02	Pakistan	+05
C		Palau	+09
Cabo Verde	-01	Palestine *	-06
Cambodia	+07	Panama	-05
Cameroon	+01	Papua New Guinea	+10
Canada - 6 time zones		Paraguay	-04
Larger western part of British Columbia,		Peru	-05
Tungsten and the associated Cantung Mine		Philippines	+08
in Northwest Territories, Yukon -08 Alberta,		Poland *	+01
some eastern parts of British Columbia, the		Portugal *	±00
Northwest Territories, Nunavut (west of		Portugal - Azores *	+01
102°W and all communities in the Kitikmeot		Q	
Region), Lloydminster -07 Manitoba,		Qatar	+03
Nunavut (between 85°W and 102°W except		R	
western Southampton Island), Ontario		Romania *	+02
(Northwestern Ontario west of 90°W with		Russia - 9 time zones	
some exceptions and Big Trout Lake area		Kaliningrad Oblast +03 Most of European	
east of 90°W), Saskatchewan except		Russia and all railroads throughout Russia	
Lloydminster -06 Nunavut east of 85°W and		+04 Bashkortostan, Chelyabinsk Oblast,	
entire Southampton Island, Ontario east of		Khanty-Mansia, Kurgan Oblast, Orenburg	
90°W (except Big Trout Lake area), the most		Oblast, Perm Krai, Sverdlovsk Oblast,	
part of Quebec -05 Labrador (all but		Tyumen Oblast, and Yamalia +06 Altai Krai,	
southeastern tip), New Brunswick, Nova		Altai Republic, Kemerovo Oblast,	
Scotia, Prince Edward Island, eastern part of		Novosibirsk Oblast, Omsk Oblast and Tomsk	
Quebec -04 Labrador (southeastern),		Oblast +07 Khakassia, Krasnoyarsk Krai and	
Newfoundland -03		Tuva +08 Buryatia and Irkutsk Oblast +09	
Central African Republic	+01	Amur Oblast, western Sakha Republic and	
Chad	+01	Zabaykalsky Krai +10 The Jewish	
Chile	-04	Autonomous Oblast, Khabarovsk Krai,	
Chile - Easter Island	-06	Primorsky Krai, central Sakha Republic and	
China	+08	Sakhalin Island +11 Magadan Oblast, eastern	
Colombia	-05	Sakha, Kuril Islands, Chukotka and	
Comoros	+03	Kamchatka Krai +12	
Congo, Republic of the	+01	Rwanda	+02
Congo, Dem. Rep. - Kinshasa	+01	S	
Congo, Dem. Rep. -		St. Kitts and Nevis	-04
Lubumbashi	+02	St. Lucia	-04
Costa Rica	-06	St. Vincent and The	-04
Cote d'Ivoire	±00	Grenadines	
Croatia *	+01	Samoa	+13
Cuba *	-05	San Marino *	+01
Cyprus *	+02	Sao Tome and Principe	±00
Czech Republic	+1	Saudi Arabia	+03
D		Senegal	±00

Denmark *	+01	Serbia *	+01
Denmark's Dependent Territories * – 4 time zones		Seychelles	+04
The most of Greenland, including inhabited south coast and west coast –03 Greenland - Thule Air Base –04 Greenland - Ittoqqortoormiit –01 Faroe Islands ±00		Sierra Leone	±00
Djibouti	+03	Singapore	+08
Dominic	–04	Slovakia *	+01
Dominican Republic	–04	Slovenia *	+01
E		Solomon Islands	+11
Ecuador	–05	Somalia	+03
Ecuador - Galapagos Province	–06	South Africa	+02
Egypt	+02	South Korea	+09
El Salvador	–06	South Sudan	+03
Equatorial Guinea	+01	Spain *	+01
Eritrea	+03	Spain - Canary Islands *	±00
Estonia *	+02	Sri Lanka	+05
Ethiopia	+03	Sudan	+03
F		Suriname	–03
Fiji	+12	Swaziland	+02
Finland *	+02	Sweden *	+01
France *	+01	Switzerland *	+01
French Overseas Territories – 10 time zones		Syria *	+02
French Polynesia - Tahiti Island –10 French Polynesia - Marquesas Islands –09 French Polynesia - Gambier Islands –09 Clipperton Island –07 Guadeloupe –04 Martinique –04 Saint Barthelemy –04 Saint Martin –04 French Guiana –03 Saint Pierre and Miquelon * –03 Mayotte +03 Réunion +04 Kerguelen Islands +05 New Caledonia +11 Wallis and Futuna +12		T	
G		Taiwan	+08
Gabon	+01	Tajikistan	+05
Gambia	±00	Tanzania	+03
Georgia	+04	Thailand	+07
Germany *	+01	Timor-Leste	+09
Ghana	±00	Togo	±00
Greece *	+02	Tonga	+13
Grenada	–04	Trinidad and Tobago	–04
Guatemala	–06	Tunisia	+01
Guinea	±00	Turkey *	+02
Guinea-Bissau	±00	Turkmenistan	+05
Guyana	–04	Tuvalu	+12
H		U	
Hait'i *	–05	Uganda	+03
Honduras	–06	Ukraine	+02
Hungary *	+01	United Arab Emirates	+04
I		United Kingdom *	±00
Iceland	±00	British Overseas Territories – 9 time zones	
India	+05	Pitcairn Islands –08 Cayman Islands –05 Anguilla –04 Bermuda –04 British Virgin Islands –04 Montserrat –04 Turks and Caicos Islands –04 Falkland Islands –03 South Georgia and the South Sandwich Islands –02 Saint Helena ±00 Ascension and Tristan da Cunha ±00 Guernsey * ±00 Isle of Man * ±00 Jersey * ±00 Gibraltar * +01 Akrotiri and Dhekelia * +02 British Indian Ocean Territory +06	
Indonesia – 3 time zones		United States of America * – 6 time zones	
Islands of Sumatra, Java, provinces of West Kalimantan and Central Kalimantan +07		Hawaii, most of the Aleutian Islands –10	
Islands of Sulawesi, Bali, provinces of East Nusa Tenggara, West Nusa Tenggara, E'st Kalimantan and South Kalimantan +08		Most of the state of Alaska –09 The states on the Pacific coast plus Nevada, parts of Idaho –08 Arizona, Colorado, Montana, New Mexico, Utah, parts of Idaho, Kansas, Oregon, North Dakota, South Dakota, Texas –07 Gulf Coast, Tennessee Valley, U.S. Interior Highlands, Great Plains, most of Texas –06 The states on the Atlantic coast, the eastern two-thirds of the Ohio Valley,	
Provinces of Maluku, North Maluku, Papua and West Papua +09			

Iran *	+03	most of Michigan -05
Iraq	+03	US Dependent Territories - 7 time zones
Ireland *	±00	Baker Island -12 Howland Island -12
Israel *	+02	American Samoa -11 Kingman Reef -11
Italy *	+01	Midway Islands -11 Palmyra Atoll -11 Jarvis
J		Island -10 Johnston Atoll -10 Navassa
Jamaica	-05	Island -05 Puerto Rico -04 US Virgin Islands
Japan	+09	-04 Guam +10 Northern Mariana Islands
Jordan *	+02	+10 Wake Island +12
K		Uruguay -03
Kazakhstan - Oral, Aktobe	+05	Uzbekistan +05
Kazakhstan 'Almaty, Astana	+06	V
Kenya	+03	Vanuatu +11
Kiribati - 3 time zones		Vatican City (Holy See) * +01
Gilbert Islands +12 Phoenix Islands +13 Line		Venezuela -04
Islands +14		Vietnam +07
Kosovo *	+01	Y
Kuwait	+03	Yemen +03
Kyrgyzstan	+06	Z
L		Zambia +02
Laos	+07	Zimbabwe +02
Latvia *	+02	
Lebanon *	+02	
Lesotho	+02	
Liberia	±00	
Libya	+01	
Liechtenstein *	+01	
Lithuania *	+02	
Luxembourg *	+01	

3.6 Setting threshold values in the Base Unit for alerting

Connect to the Base Unit and click on “EDIT” located on the upper right corner just below the menu button. You will now see the button change into “Updated and Reset”

Sensors

Status	Type	Name	Value
	Temperature	Int. Temp1	29.61 °C
	Zigbee 1	WT-0221	25.93 °C

Update Reset

Warning Range		Down Range		Repeat Alarm	Email	SMS	SNMP Trap	Set Output To	
<	18	<	15	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	DISABLE	-
>	37	>	41						
<	18	<	15	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	-
>	30	>	29						

Status: this shows if the internal sensor or the external sensor probe is working or not

Type: type of reading for the sensor

Name this is the name of the sensor and will be used in alerting

Value: this is the latest reading for both the internal sensor and the external sensor probe

Warning range: below the minimum value and above the maximum value a WARNING alert will be sent. Current value color will change to orange

Down range: below the minimum value and above the maximum value a DOWN alert will be sent. Current value color will change to red. DOWN overrules WARNING

Repeat alarm: when set then this will trigger an alert to be sent every 5 minutes Only if the status is on a DOWN state.

Email: when checked then email alerts will be sent for this sensor value

SMS: When checked then SMS or Voice call alerts will be sent for this sensor value

SNMP trap: when checked then a SNMP Trap will be sent for this sensor value

Note that the repeat alarm is customizable from the settings menu under General Settings.

4 Base Unit alerting feature

4.1 Email alerting

The InfraSensing sensors can generate autonomous alerts via SNMP Traps and also via email. Make sure that the email checked as one of the alerting options for any of your sensors.

Repeat Alarm	Email	SMS	SNMP Trap
<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

To setup email alerting, Go to the menu option, then settings and then click on the **Email** option under Industrial and external use.



This screen consists of 3 main parts:

Mail server settings

Mail heading settings (from, to, subject ...)

Mail content (body)

NOTE : Please make sure you have whitelisted us in your system so that these emails can be delivered without delay or disruption. Also, we don't currently support gmail as of the moment, only outlook and yahoo.

Email Alert

Enable Email Alerts

☐

SMTP Server

mail.serverscheck.email

SMTP Port

465

SSL (v3)

☐

Use SMTP Authentication

☒

SMTP Username

Test

SMTP Password

From Email

Manual@serverscheck.com

To Email

Customer@gmail.com

CC

Note: Sending to multiple recipients can be separated by a comma however in respect to the "To" and "Cc" fields, To is limited to 90 characters and Cc is limited to 70, So if you need to send an email to multiple addresses then it is advised that you create a "group mail" and use that instead.

For email alerting, InfraSensing supports standard outgoing mail servers like the ones used by ISP's (SMTP relay servers) or corporate SMTP mail servers requiring standard username & password authentication. SSL mail servers are not supported. For use of SSL, web-based emails are recommended.

In some cases, it may happen that you don't have a non-SSL server available in your network or from your ISP. In such situations, we have 4 alternative solutions that may fix the issue.

4.2 Email alerts using the ADDON-LTE

Settings & Info

Device information

Account name	admin
	Change Password
Current System Date	08 Feb 2020
Current System Time	01:49:43
	Update Time
Hardware Version	Release 5.1
Firmware Version	Release 8.20 (Feb 7 2020)
	Upgrade Firmware
Mac Address	00:03:64:03:6A:A4
IP Address	192.168.11.60
	Change IP
Node Status (online/used/max)	24/50/51
	Calibrate Sensors
	Cellular Add-On

Access the base unit and go to settings, under settings click on the Cellular Add-On button and then scroll down to access the email configuration.

Note: (see section for the ADDON-LTE) The built-in email feature of the Base Unit will be disabled upon using the ADDON-LTE

ADDON-LTE Config

Primary Mode

Backup Mode

SMTP Port

SMTP Port

SMTP Username

SMTP Password

Add on Status

LAN/RTN

Network Status

Active SSID

Network Name

Signal Bar

SSID

SSID

SSID Password

Append to Email this text

SMTP Server

SMTP Port

Secure connection

Use SMTP Authentication

SMTP Username

SMTP Password

From Email

To Email(s)

Email Subject

Append to Email this text

GPS Status

Fix

Subsidiary Fix

Latitude

Longitude

Submit

Reset

SMTP Server

SMTP Port

Secure connection

Use SMTP Authentication

SMTP Username

SMTP Password

From Email

To Email(s)

Email Subject

Append to Email this text

Send test Email

Input your email settings and perform a test mail, the ADDON-LTE is tested to work on our free email server, Gmail and yahoo mail. (Continue reading for sample email set up).


4.2.1 Gmail as e-mail server (<https://mail.google.com>)

To use Gmail as a mail server, you need to have a Gmail account. You may sign up for one at <https://mail.google.com> and port 25 should not be blocked by your ISP.

THINGS TO SET UP FOR GMAIL


Below are the instructions on how to set it up.

1. Log in to your Gmail Account and access "Manage your Google Account."



2. On the search bar type in "App Passwords."

Note: Make sure that your 2-factor authenticator is enabled so that you can access the "App Passwords"



3. Once you click “App Passwords” you will see this pop up message. Just click “Select App” and choose “Other”

← App passwords

App passwords let you sign in to your Google Account from apps on devices that don't support 2-Step Verification. You'll only need to enter it once so you don't need to remember it. [Learn more](#)

You don't have any app passwords.

Select the app and device you want to generate the app password for.

Select app ▼ Select device ▼

GENERATE

Select app

- Mail
- Calendar
- Contacts
- YouTube
- Other (Custom name)**

4. After you choose “Other” you may type in the name of your device or any name you desire.
5. Once you put in the name of your device, you may now click “Generate” so that it will generate you a password that you need to save for later.

← App passwords

App passwords let you sign in to your Google Account from apps on devices that don't support 2-Step Verification. You'll only need to enter it once so you don't need to remember it. [Learn more](#)

You don't have any app passwords.

Select the app and device you want to generate the app password for.

Base Unit ✕

GENERATE

6. After you click “**Generate**” a pop message will appear. This is now your app password for your device.

Important: Make sure to copy and securely store this password in your notes for future reference. Once you close this pop-up message, the password will not be retrievable. In case you lose it, you will need to follow the same steps again to generate a new password.

Generated app password

Your app password for your device

tezy gpyj eohp aauc

How to use it

Go to the settings for your Google Account in the application or device you are trying to set up. Replace your password with the 16-character password shown above. Just like your normal password, this app password grants complete access to your Google Account. You won't need to remember it, so don't write it down or share it with anyone.

DONE

Email

securesally@gmail.com

Password

••••••••••••••

Non-Secure Settings

SMTP Server: aspmx.l.google.com

SMTP Port: **25**

SMTP Authentication: **Off / Unchecked**

From address: yourgmailname@gmail.com To
address: same as from address

The emails will arrive in your SPAM filter unless you whitelist the IP address on Gmail from which you are sending the alerts.

For SSL, the settings will be:

SMTP Server: smtp.gmail.com

SMTP Port: **465**

SMTP Use SSL: **Checked**

SMTP Authentication: **Checked**

SMTP Username/Password: **Filled out**

From/To address: Filled out. Not required to be the same.

For TLS, the settings will be:

SMTP Server: smtp.gmail.com

SMTP Port: **587**

SMTP Use SSL: **UnChecked**

SMTP Authentication: **Checked**

SMTP Username/Password: **Filled out**

From/To address: Filled out. Not required to be the same.


Note: Only version 5 Base Units are supported with Gmail's SSL ever since they offered RSA 2048-bit encryption.

4.2.2 Outlook mail as e-mail server (<https://outlook.live.com>)


Outlook mail is another example of an SMTP server, which can be used on the gateway

However, you have to turn the option for “Let devices and apps use POP” to YES and then make sure you save it.

To do so just log in onto your account and click on the settings icon beside your log-in name. Then choose options.



Then Click on “Mail” on the left panel to expand it then expand “Accounts” then click on “POP and IMAP”



Now choose YES under “let device and app use POP” and save it.

You can now set the gateway using the SMTP settings of outlook mail.

For TLS, the settings will be:

SMTP Server: smtp-mail.outlook.com

SMTP Port: **587**

SMTP Use SSL: **UnChecked**

SMTP Authentication: **Checked**

SMTP Username/Password: **Filled out**

From/To address: Filled out. Not required to be the same.

Note:

Check if your account allows User Consent to apps:

1. In the admin center, go to **Settings>OrgSettings>Services** page, and select **User Consent to apps**.
2. On the **User consent to apps** page, select the option to turn user consent on or off.


4.2.3 Using InfraSensing premium e-mail (<https://my.InfraSensing.com>)

****A premium Account is free to create and is required to enjoy the service ****

1. Log in to your InfraSensing Premium account and click on Alerts and then **Email Alerts** or simply log in and go to this link <https://my.infrasensing.com/email/>




2. You should now see the configuration you have to copy in to your gateway's email settings to receive alerts using your accounts UID and PIN.




Note: Make sure you copy all details and leave the box for SSL unchecked. The service is FREE on every premium account.

4.3 Slack channel integration via e-mail alerts

To receive alerts via slack we first need to have the email app integrated into our slack account



As shown on the image above we need to add the email app into our slack account.



Email

Send emails directly to a channel in Slack.

This integration gives you a special email address that you can use to subscribe to important notifications from any service. Emails sent to this address will show up in your channel of choice. This integration is available to workspaces on the Slack Standard Plan and above.

Example uses include:

- Send results from a contact form on your website into your company's #support channels instantly.
- Alerts of all kinds (server down, weather events, traffic closures, domain name renewals) can be pointed at your company's #general channel for all to see and act upon.

Each integration has its own email address and a customizable name and icon, and you can create as many of them as you like.

Please note that the following limits apply to emails sent to this integration:

- The combined headers and body of an email cannot be larger than 1MB.
- When combined with attachments, an email cannot be larger than 30 MB.
- There is a maximum of 20 attachments per email.
- You can address each email to one integration at a time.

Post to Channel

Start by choosing a channel where email will be posted.

• Email alerts


Add Email Integration

Once we add the app you will be prompt to choose a channel were the alerts will be received

Integration Settings

Email Address

Emails sent to this address will be imported into Slack.


other.slackify@f325mrmx.chesnotsk.com

☐ Hide this address

Anyone in your workspace can view this email address and send email to it.

Post to Channel

Emails will be posted here. They will be kept private if posted to a private group or direct message.

• Email alerts

Descriptive Label

Use this label to provide extra context in your list of integrations (optional).

Optional description of this integration

Customize Name

Choose the username that this integration will post as.

email

Once done you will then see the email address that you can use to receive alerts, you can place the email address on the “To” or “Cc” field see **section 4.1**.


4.4 Tunneling an SSL connection

In this guide we will be using the STunnel software installed on our InfraSensing Monitoring Appliance.

You can use STunnel to allow non-SSL devices such as the Base Unit to connect to a secure mail server in which the Base Unit will connect to STunnel using non-SSL SMTP then STunnel will bridge the connection to for example Google Mail using an SSL connection.

Network Diagram

The Image below will show that the gateway sends via Non-SSL smtp connection going to the monitoring appliance, the data is then relayed using an SSL/TLS connection going to Gmail's smtp server.



How to do it:

1. Download and Install the STunnel Software (can be downloaded from: <http://www.stunnel.org/>)
2. During the installation you will be prompt to input details, which will be needed to created certificates.

```
C:\Program Files (x86)\stunnel\bin\openssl.exe
WARNING: can't open config file: /dev/win32/openssl/openssl.cnf
Generating a 2048 bit RSA private key
.....+++
....+++
writing new private key to 'C:\Program Files (x86)\stunnel\config\stunnel.pem'
-----
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.
-----
Country Name (2 letter code) [PL]:BE
State or Province Name (full name) [Mazovia Province]:Zaventem
Locality Name (eg, city) [Warsaw]:Leuvensesteenweg
Organization Name (eg, company) [Stunnel Developers]:ServersCheck
Organizational Unit Name (eg, section) [Provisional CA]:Application Support
Common Name (FQDN of your server) [localhost]:FoxHound
```

3. Access the config folder as shown in the image below and open stunnel.conf using a text editor.
Ex. Notepad, Notepad++

This PC > Windows (C:) > Program Files (x86) > stunnel > config				
<input type="checkbox"/> Name	Date modified	Type	Size	
<input type="checkbox"/> ca-certs.pem	07/06/2017 4:22 A...	PEM File	254 KB	
<input type="checkbox"/> openssl.cnf	17/01/2017 4:12 A...	CNF File	2 KB	
<input checked="" type="checkbox"/> stunnel.conf	28/01/2017 5:04 PM	CONF File	5 KB	
<input type="checkbox"/> stunnel.conf.old2	30/08/2017 5:55 PM	OLD2 File	1 KB	
<input type="checkbox"/> stunnel.pem	31/08/2017 5:20 PM	PEM File	4 KB	


4. You should be able to see sample configuration commands. You can either edit the current or add the configuration below. Then save the file.

```
[gmail-pop3]
client = yes
accept = 110
connect = pop.gmail.com:995
verifyChain = yes
CAfile = ca-certs.pem
checkHost = pop.gmail.com
OCSPaia = yes
```


```
[gmail-imap]
client = yes
accept = 143
connect = imap.gmail.com:993
verifyChain = yes
CAfile = ca-certs.pem
checkHost = imap.gmail.com
OCSPaia = yes
```

```
[gmail-smtp]
client = yes
accept = 25
connect = smtp.gmail.com:465
verifyChain = yes
CAfile = ca-certs.pem
checkHost = smtp.gmail.com
OCSPaia = yes
```


5. Make sure STunnel is added on your allowed application in the firewall list




- Click on the desktop icon of the STunnel. You can also see and choose options on the Icon created on the system tray.



- You should see a result like the image below once successful.



- Check the IP address of the Appliance/Computer. In this example our Monitoring Appliance is at 192.168.9.16. (Note: One method to get the IP address of the Monitoring appliance is by opening a command prompt and typing in the command “ipconfig”)



9. Access your gateway and go to email alerts. Then configure as shown in the image.
(192.168.9.16 is the IP of the Monitoring Appliance where STunnel is installed)

Email Alert

Enable Email Alerts	<input checked="" type="checkbox"/>
SMTP Server	192.168.9.16
SMTP Port	25
SSL (v3)	<input type="checkbox"/>
Use SMTP Authentication	<input checked="" type="checkbox"/>
SMTP Username	test
SMTP Password
From Email	Manual@serverscheck.com
To Email	Customer@gmail.com
CC	
We recommend the use of distribution group	
Email Subject	
Email Body	

10. Then click on submit and check if the email was sent successfully.

4.5 Mail service like AuthSMTP.com

If you don't have a non-SSL mail server on your network and you don't want to use STunnel and you can't use Gmail because your operator blocks it, then we could recommend AuthSMTP.com which provides a solid SMTP relay service.

With AuthSMTP.com you can subscribe to use their relay servers on a port such as 2525 while using standard authentication (non-SSL).

More information on <http://www.authsmtp.com>


Note:

If you need to send alerts to multiple recipients, then the best option is to create a group in your mail server to send out the email alerts to multiple people.

In the email body we suggest to put in the location of the sensor. When you have multiple sensors, a user easily knows where to look for when receiving the alert.

When done click on the **Submit** button. It will now try to send a test message to the mail account.

Below is the test email as received in Outlook 2010.



4.6 SMS alerting from Base Unit

4.6.1 SMS alerts via ADDON-LTE

SMTP Server

SMTP Port

Secure connection

Use SMTP Authentication

SMTP Username

SMTP Password

From Email

To Email(s)

Email Subject

Append to Email this text

Send test Email

Access the base unit and go to settings, under settings click on the Cellular Add-On button to access the configuration.

Note: The built in Premium SMS feature of the Base Unit will be disabled upon using the SMS functionality of the LTE addon

ADDON-LTE Config

Primary Mode

Backup Mode

SIM1 PIN

SIM1 APN

SIM1 Username

SIM1 Password

Add-on Status

Last Error

Network Status

Active SIM

Network Name

Signal Band

RSSI

RSL

2G/3G Recipients

Append to SMS this text

SMTP Server

SMTP Port

Secure connection

Use SMTP Authentication

SMTP Username

SMTP Password

From Email

To Email(s)

Email Subject

Append to Email this text

GPS Status

PPS

Subscribes Found

Lat/Long

Longitude

Send test Email

Enter the SIM information, if the SIM does not have a security PIN then leave it blank.

ADDON-LTE Config

Primary mode ☐ Backup mode ☒

SIM PIN: SIM PIN:

SIM APN: SIM APN:

SIM Username: SIM Username:

SIM Password: SIM Password:

Att on Status Last Error

Network Status
Active SIM
Network Name
Signal Band
RSSI
RSC

SMS Recipients
Append to SMS this text

SMS Recipients

Append to SMS this text

Send test SMS

From Email
To Email(s)
Email Subject
Append to Email this text

Send test Email

GPS Status
Fix
Subsides Found
Latitude
Longitude

No Fix
0
0.00000
0.00000

Update Reset

A maximum of 5 recipients can be added separated by a comma.

Update Reset

	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To	
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	DISABLE	-
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	-

Make sure that the SMS checkbox is ticked to receive alerts via SMS for the sensors you are monitoring.

4.6.2 SMS alerts via my.infrasensing premium credits

Requirements for SMS alerting:

An active account created on <https://my.infrasensing.com>


An active Premium Plan

Firmware 2.10 or higher on Base Units

Outbound communication on port 80 from Base Unit to Internet


For SMS alerting, SMS messages are sent by InfraSensing's SMS Gateway. Base Units make a connection over TCP/IP with the SMS Gateway servers for delivering SMS messages.

As per above requirements you need to create an account first on <https://my.infrasensing.com>




The screenshot shows the login page of the my.serverscheck.com portal. It features a search bar at the top right. The main content area has a login form with fields for 'Email address' and 'Password', followed by a blue 'Sign in' button. Below the button are links for 'Forgot Password?' and 'Create an Account'. A yellow informational box at the bottom states: 'You can login here with your Premium account details. All Premium accounts have been transferred to this new customer portal.'

When you have completed above steps to create your account, then you will receive an email with your username and temporary password to login.



Note: Premium Credits are required for the SMS & Voice feature, Credits can be purchased through your account.

To check for the configuration and remaining SMS/Voice Call Credit we need to click on the “Alerts” Icon and then “SMS” in the middle of your Home page.




The screenshot shows a web interface for SMS configuration. At the top is an orange header with a refresh icon. Below it is a breadcrumb trail: Home / SMS. A large orange button labeled "Purchase Credits" is prominent. Underneath, there's a yellow box containing labels for "Alerts UID:" and "PIN:" next to input fields. Below this is a button labeled "generate new alert uid" with a right-pointing arrow. At the bottom, there's a "Show 10 entries" dropdown menu.

You need to note down the following configuration info: the **UID** and **PIN** codes. These have to be entered in the Base Unit in order to have the SMS alerting work. You may also Generate a new alert UID, should you wish to do so.

From the above personal page, you can check your SMS credits status, Upgrade into New Plans or check your SMS alerting history. You can also add additional SMS recipients if you want SMS alerts to be send to multiple mobile numbers.

Now connect to your Base Unit, click on the Menu button and go to settings then click on SMS



The screenshot shows the "SMS & Voice Call Alert Settings" page. It features a toggle switch for "Enable SMS & Voice Call". Below this are input fields for "UID" and "PIN". At the bottom left are "Update" and "Reset" buttons. A light blue informational box at the bottom states: "You can find your Alert UID and PIN code in your myServersCheck account. The use of SMS requires the purchase of SMS credits a Click [here](#) to access / create your myServersCheck account."

Activate the **Enable SMS& Voice Call** option. Then enter the **UID** and **PIN** from your account page. Click on the **Submit** button and wait for an SMS test alert to be sent on your cell phone.

Didn't you receive the SMS test alert? Verify your network settings especially if the DNS server has been configured correctly in the **Network** menu settings. If the DNS server has been correctly defined then make sure that no firewall is blocking outgoing HTTP calls from the Base Unit to the InfraSensing SMS Gateway.

Update

Reset


	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To	
<div><div></div><div></div></div>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<div>DISABLE</div>	<div>-</div>
<div><div></div><div></div></div>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<div>DISABLE</div>	<div>-</div>

Now click on the SMS checkbox to receive alerts via SMS for the item you are monitoring.

4.6.3 Sending SMS alerts and JSON Push data using the Microservice feature

Starting from Base Unit firmware 8.7, the Microservice feature of the Base Unit lets you send SMS alerts and JSON Push data through the ADDON-LTE of another Base Unit that is within the same network.

How the Microservice works




Requirements:

- Base Unit to use the feature
- Base Unit with connected ADDON-LTE(with attached SIM card) to host the Microservice
- Both Base Units must be on the same network

Setting up the host Base Unit

1. On the Web Interface of the Base Unit, go to the Menu > Settings > IoT. You should be able to see a window like this:



IoT Connectivity

Send Data to Cloud ☒

URL

Device ID

Username

Password

Update interval every min

2. Turn on Send Data to Cloud.
3. Fill in the following data:
 - URL that will receive JSON Push data
 - Device ID of the Base Unit (alphanumeric)
 - Username and Password
 - Update interval of the Base Unit to send data over the Microservice
4. After the details are entered, click **Update**.

Setting up the Base Unit that will use the Microservice

1. On the Web Interface of the Base Unit, go to Menu > Settings > Microservice.

Take note that the Microservice Settings button will only appear on Base Unit with firmware version 8.7 and up.

You should be able to see a window like this:

Microservice Settings

Send Alerts Through Microservice ☒

Microservice Gateway IP Address 192.168.11.123

IOT

Device ID 000000000000

Username admin

Password *****

Update interval every 5 min

IOT URL should be configured on the Microservice Gateway

Test SMS Recipients +639991234444

SMS recipients should be configured on the Microservice Gateway

Test SMS Text test message

Send Test SMS

Update Reset

2. Turn on the Send Alerts Through Microservice.
3. Fill in the following data:
 - The Microservice Gateway IP Address (host IP Address)
 - Device ID of the host Base Unit
 - Username and Password of the host
 - Update interval
4. Click **Update**.

Sending Test SMS for Microservice

Microservice Settings

Send Alerts Through Microservice ☒

Microservice Gateway IP Address 192.168.11.123

IOT

Device ID 000000000000

Username admin

Password *****

Update interval every 5 min

IOT URL should be configured on the Microservice Gateway

Test SMS Recipients +639991234444

SMS recipients should be configured on the Microservice Gateway

Test SMS Text test message

Send Test SMS

Update Reset



1. On the Microservice Settings, fill in the mobile numbers for the Test SMS Recipients.
2. Input the Test SMS Text that the recipients should receive.
3. Click **Send Text SMS**.

4.7 Voice call alerts


Aside from SMS messages, InfraSensing also offers voice calls as an alert by using text-to-speech technology. This feature could be utilized to monitor your mission-critical environments and/or devices. It works by dialing the recipient's number then informing him/her of the error message.

Voice call alerts are configured on the SMS portal and can be used by purchasing the same credits used for your SMS alerts.

To get started, add a new recipient by proceeding to the "Manage Numbers" page of the SMS portal. From there, as seen on the screenshot below, you'll have to choose the alert type for the new recipient which can be for SMS, voice call, or both.



Fill in the required fields



Then select “Voice” or “SMS and Voice”

After which, you’ll have to verify the added number by clicking the “Activation Pending” link as seen below.

Number	Alert Type	Description	Status	Actions
0123456789	SMS & VOICE		Activation Pending	edit delete
0123456789	VOICE		Active	edit delete

Once activated, we’ll have to go the Base Unit’s web page to specify the sensors where you want the voice call alert to be used. In order to do so, make sure the SMS and Voice Call alert option on the Settings page is ticked.

Update Reset

	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To	
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	DISABLE	-
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	-

Depending on the active recipients on the SMS portal, each time the specified sensor sends an alert, you will receive an SMS and/or voice call alert(s). If the active recipient(s) is only enabled for SMS, then you'll only be receiving an SMS alert. Other options are voice only, or both SMS and voice.

4.8 Retest before alarm

Retest before alarm is one of the newest features that verifies alerts to prevent false alarms before triggering a genuine one. This feature also empowers you to specify the number of checks before initiating a real alarm.

To adjust how times the alarm will be checked, navigate to 'Settings' and under 'General Settings', locate 'Retest Before Alarm'. By default, it is set to zero (0), but you can modify it by typing the desired number or using the up and down arrow buttons.

General settings
 Device Name
 Device Location
 Sensor Polling
 Temperature Unit
 OLED Screen
 Repeat Alarm Time
Retest Before Alarm
 Web Server

SensorGateway
 Data Center
 every 1 sec
 Celsius
 Enable
 every 5 min
 3 times
 Enable


Update
Reboot
Legal Info

Once you input your desired number you may now click on update to apply the changes.

4.9 Maintenance Mode

Maintenance Mode is one of the newest features that can be found in the latest firmware version 9.1.


Enabling the Maintenance Mode allows you to configure the sensors without triggering any alerts, even when the alerting is enabled. In order to enable this feature, just click on the button "Enable Maintenance mode". Please see image below for reference.



The screenshot shows the 'Sensors' page with a table of sensor data. A red box highlights the 'Enable Maintenance Mode' button, which is located in the top right corner of the page. An arrow points from the text 'Enable Maintenance Mode' to the button.

Status	Type	Name	Value	Warning Range	Down Range	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To
Red	Temperature	Int. Temp1	30.58 °C	<18 OR >29	<15 OR >30	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Output1 <input type="button" value="v"/> ON <input type="button" value="v"/>
Green	Ping	Int. Ping1	48 ms	>50	>60	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	DISABLE <input type="button" value="v"/> - <input type="button" value="v"/>

Once you click "Enable Maintenance Mode," it will change to "Disable Maintenance Mode." To deactivate it, simply click again.




The screenshot shows the 'Sensors' page with a table of sensor data. A red box highlights the 'Disable Maintenance Mode' button, which is located in the top right corner of the page. An arrow points from the text 'Disable Maintenance Mode' to the button.

Status	Type	Name	Value	Warning Range	Down Range	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To
Red	Temperature	Int. Temp1	30.58 °C	<18 OR >29	<15 OR >30	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Output1 <input type="button" value="v"/> ON <input type="button" value="v"/>
Green	Ping	Int. Ping1	46 ms	>50	>60	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	DISABLE <input type="button" value="v"/> - <input type="button" value="v"/>

4.10 Fault Sensor

Fault Sensor is one of the newest features that can also be found in the latest firmware version 9.1. Whenever this feature is enabled, by default it will trigger an alert when a sensor gets disconnected. Also, it will send an alert if a sensor sends a zero value. In order to configure this feature, click on the Fault Sensor button at the bottom of the page, please refer to the image below.




The 'Fault Config' page has an orange header bar with a refresh icon and a menu icon. The main content area is divided into three sections labeled A, B, and C. Section A contains a toggle switch for 'Enable Fault Sensor', which is currently turned on. Section B contains a toggle switch for 'Trigger Internal Fault If Sensor Sends Zero Value', which is also turned on. Section C contains a 'Reset Missing Sensors Fault' button labeled 'Reset'. At the bottom of the page are 'Update' and 'Reset' buttons. A table in the middle of the page shows sensor configurations.

Sensor Type	Min Threshold	Max Threshold
CO2	400.00	5000.00
VOC	0.00	500.00

- A. Enable Fault Sensor – When this feature is enabled, it will send out an alert whenever a sensor gets disconnected.
- B. Trigger internal Fault if Sensor Sends Zero Value – Enabling this feature will generate an alert whenever a sensor transmit a zero value.
- C. Reset Missing Sensors Fault – This option enables you to reset Fault alerts triggered by missing sensors.

5 History

5.1 Alert history




Each time a threshold is hit, an entry is automatically recorded on the log. And as seen on the screenshot, recovery alerts are also included. The Base Unit is able to store up to 2048 entries and are downloadable in CSV format. On column F of the CSV file, the following legend is used for the alerts - 0:Recovery; 1:Warning; 2:Down.

Alert History

Download as csv

2019/02/13 05:30:10	Recover	WT-0221	28.68
2019/02/13 05:29:09	Down	WT-0221	29.06
2019/02/13 05:24:08	Recover	WT-0221	28.87
2019/02/13 05:23:08	Down	WT-0221	29.12
2019/02/13 05:20:06	Recover	WT-0221	28.93
2019/02/13 05:18:06	Down	WT-0221	29.12
2019/02/13 05:16:05	Recover	WT-0221	28.87
2019/02/13 05:15:05	Down	WT-0221	29.18
2019/02/13 05:14:05	Recover	WT-0221	29.00
2019/02/13 05:05:01	Down	WT-0221	29.12
2019/02/13 03:01:40	Warning	WT-0221	26.00
2019/02/13 02:52:55	Recover	Ext. Temp2	24.82
2019/02/13 02:52:53	Warning	Ext. Temp2	25.60
2019/02/13 02:12:53	Recover	Ext. Temp2	22.74
2019/02/13 02:12:52	Warning	Ext. Temp2	25.64
2019/02/13 02:11:53	Recover	Ext. Temp2	23.07
2019/02/13 02:11:50	Warning	Ext. Temp2	27.75
2019/02/13 02:05:50	Recover	Ext. Temp2	24.82
2019/02/13 02:05:35	Warning	Ext. Temp2	27.15
2019/02/13 02:04:50	Recover	Ext. Temp2	24.78
2019/02/13 02:03:30	Down	Ext. Temp2	32.16

5.2 Fault history



Each time there's a Fault triggered; an entry is automatically recorded on the log. This can also be downloaded as csvs.

Fault Alert History					
Download as csv					
2024/02/21 19:40:42	Fault	Hub Port 7	Probe Missing	Triggered	
2024/02/21 19:40:37	Fault	Hub Port 8	Probe Missing	Triggered	
2024/02/21 19:39:12	OK	Particle1	CO2/VOC Limit	Recovered	
2024/02/21 17:59:40	Fault	Hub Port 4	Probe Missing	Recovered	
2024/02/21 17:50:26	Fault	Hub Port 4	Probe Missing	Triggered	
2024/02/21 16:49:37	Fault	VOC Sensor1	CO2/VOC Limit	Triggered	
2024/02/21 16:48:21	Fault	VOC Sensor1	CO2/VOC Limit	Triggered	
2024/02/21 15:11:20	Fault	VOC Sensor1	CO2/VOC Limit	Triggered	
2024/02/21 15:09:08	Fault	VOC Sensor1	CO2/VOC Limit	Triggered	
2024/02/21 14:34:11	Fault	Hub Port 3	Probe Missing	Triggered	
2024/02/21 14:33:20	Fault	VOC Sensor1	CO2/VOC Limit	Triggered	
2024/02/21 14:33:16	Fault	Hub Port 7	Probe Missing	Triggered	
2024/02/21 13:24:07	Fault	Port 2	Probe Missing	Triggered	
2024/02/21 13:21:13	Fault	Port 2	Probe Missing	Triggered	
2024/02/21 13:21:11	Fault	Port 1	Probe Missing	Triggered	
2024/02/21 12:44:32	Fault	Port 2	Probe Missing	Triggered	
2024/02/21 12:39:01	Fault	Hub Port 7	Probe Missing	Triggered	
2024/02/21 12:39:01	Fault	Hub Port 6	Probe Missing	Triggered	
2024/02/21 12:39:01	Fault	Hub Port 5	Probe Missing	Triggered	
2024/02/21 12:39:01	Fault	Hub Port 3	Probe Missing	Triggered	
2024/02/21 12:39:01	Fault	Hub Port 1	Probe Missing	Triggered	
2024/02/21 12:39:01	Fault	Hub Port 4	Probe Missing	Triggered	

6 Configuring the Base Unit for SNMP

In this section we are going to explain how the InfraSensing sensors can interact with SNMP enabled management systems.

The Base Unit supports 2 kinds of SNMP messages:

- **Pulling:** a network management system's requests status for the sensors through SNMP get requests
- **Pushing:** the Base Unit pushing SNMP notifications (called SNMP Traps) to network or building management systems

To illustrate SNMP, we will use the free (for personal use) SNMP Browser from iReasoning which is available from the following URL: <http://ireasoning.com/mibbrowser.shtml>


6.1 SNMP get requests

In the Base Unit the built-in SNMP agent needs to be enabled to allow for querying of the sensor by external applications using the SNMP GET protocol.

The Base Unit has its own MIB file, which can be downloaded here:

<http://downloads.infrasensing.com/sensors/Base Unit.mib>

1. To enable SNMP, connect to the Base Unit, Click on the menu button and go to settings and then under industrial and external communications *toggle on “SNMP”* and click *Update*.



Community string is limited to 16 characters.

2. You need now to enable the **SNMP Agent**. Click on *SNMP* to proceed to the SNMP settings.



3. On the SNMP Settings, click on the *SNMP Agent* toggle and enter the *Port* number to be used (default port for this UDP is 161 for Windows OS and 5555 for MAC OS). If you want to use a different community string, then you can change the value up to 16 characters. Default value for a read community is typically *public*, and *private* for write community.

4. Select the SNMP Version (SNMPv2 or SNMPv3). Refer to the illustration for settings of each version:

SNMP Agent	
SNMP Agent	<input checked="" type="checkbox"/>
Port	161
Version	SNMPv2
SNMP Read Community	public
SNMP Write Community	private

SNMP settings for v2


SNMP Agent	
SNMP Agent	<input checked="" type="checkbox"/>
Port	161
Version	SNMPv3
SNMP Read Community	public
SNMP Write Community	private
Username	Serverscheck
Auth Key	auth12345
Protocol	MD5
Privacy Key	priv12345
Protocol	AES

SNMP settings for v3

Note. On v3, additional settings will appear. Select a username, then select *MD5* and *AES* for the 1st and 2nd Protocol respectively, and enter an Auth Key and Privacy Key.

5. After all the SNMP settings are done, click *Update*.

6. Now let's proceed to opening the iReasoning MIB Browser.



iReasoning MIB Browser main screen

7. Set the Address field to the IP address of your Base Unit.




8. Next, click **Advanced** to go to the advanced properties of the SNMP agent.

9. In the Advanced Properties window, enter the following details:

- IP Address of the Base Unit
- Copy details from the SNMP settings of the Base Unit such as Read and Write Community string, and Port number


10. Select the SNMP version (2 or 3)

Note. When SNMP Version 3 is selected, there will be additional settings to fill out. For the *Security Level*, select *auth, priv* then for the rest, copy from the SNMP settings of the Base Unit.




For the remaining settings of SNMPv3, leave it blank and it will later have values after it has undergone the SNMP Walk operation.

11. After the SNMP v2 or v3 settings are entered, click OK.
12. Go to the main screen and perform SNMP walk by selecting Walk on Operations and then click Go.



13. The image below shows the example output of the SNMP walk.



In the above screen copy you see all the SNMP parameters as made available by the InfraSensing Base Unit.

At the bottom you will see the values of the internal temperature sensor connected to the appliance (**sensor1Value.0**) and then of the values returned by external sensor probes connected to it.


In this example we added an external temperature & humidity probe to it. By clicking on a field, you can see the matching OID for that field at the top. In above example the OID for the humidity reading is **.1.3.6.1.4.1.17095.3.10.0**

Note: for Firmware 7.5 and above a new OID structure is implemented which would have sensor values as String and Integer. The update will not affect the OLD OID structure and can still be used.

Below is an Example of the new structure added on top of our current structure.

1.3.6.1.4.1.17095.1010.10.3.0	25.62	OctetString	192.168.11....
1.3.6.1.4.1.17095.1010.10.4.0	25	Integer	192.168.11....
1.3.6.1.4.1.17095.1010.10.5.0	WARNING	OctetString	192.168.11....
1.3.6.1.4.1.17095.1010.10.6.0	1	Integer	192.168.11....
1.3.6.1.4.1.17095.1010.10.7.0	WARNING	OctetString	192.168.11....
1.3.6.1.4.1.17095.1010.10.8.0	05 July 2018, 14:49:47	OctetString	192.168.11....

Note. After the walk operation, the SNMPv3 advanced properties(Engine ID, Localized Auth Key and Localized Priv Key) will have values. The engine ID is composed of the initial default value and followed by the MAC Address of the Base Unit. It can be seen by looking into the Main Settings of the gateway.



IMPORTANT NOTE:

In any cases you encounter or experience where the OID changes whenever a sensor is unplugged please note that this is because you are using an OLD SNMP structure.

With the introduction of the new structure, the SNMP OIDs will remain fixed and will not change whenever a sensor is unplugged.

The OID for the new structure starts with


.1.3.6.1.4.1.17095.8.1.1.0 and ends with **.1.3.6.1.4.1.17095.8.50.9.0**.

If you have recently updated your firmware to version 9.2, please perform an SNMP WALK to check the OIDs for the Sound Meter and Pressure sensor on the new structure.


6.2 SNMP traps

When threshold values are exceeded or on failure (water detection or power failure), the Base Unit can send out SNMP Traps to network management systems.

1. On our system we have installed the iReasoning MIB Browser. Go to **Tools > Trap Receiver**



2. In the Trap Receiver, click on the Tools button for SNMP Trap settings. Set the Trap Receiver Port. This is the UDP port used by the SNMP Trap Receiver to receive incoming messages. In our example we set it to 5555.



For SNMPv3, additional settings should be added by going to the *SNMPv3 Trap Receiver* tab and then click *Add*, the Add SNMPv3 Parameters will show, then copy the SNMPv3 settings from the Base Unit to the iReasoning MIB Add SNMPv3 Parameters. After that, click *Ok*.

The image shows two screenshots from a software interface. The top screenshot is a window titled 'Trap Receiver' with tabs for 'Result Table', 'Operations', 'Tools', and 'Database'. The 'Trap Receiver Settings' section is active, with sub-tabs for 'General', 'SMTP', and 'SNMPv3 Trap Receiver'. The 'SNMPv3 Trap Receiver' tab is selected, showing fields for 'Auth Protocol', 'Auth Password', 'Priv Protocol', and 'Priv Password'. The bottom screenshot is a dialog box titled 'Add SNMPv3 Parameters' with the following fields: 'Username' (Serverscheck), 'Authentication Protocol' (MD5), 'Authentication Password' (masked with asterisks), 'Privacy Protocol' (AES), 'Privacy Password' (masked with asterisks), and 'Security Level' (auth, priv). There are 'Ok' and 'Cancel' buttons at the bottom of the dialog.

The iReasoning is now ready to receive SNMP Trap alerts from the Base Unit.

3. Go back to the Base Unit to set the SNMP Trap Alerts by:
 - 3.1. Click on the Enable 1st Trap Receiver
 Note: With the firmware version 7.40 and above you can have up to 2 trap receivers meaning you can install iReasoning or any trap receiver on any two computers and have the gateway send trap alerts on both.
 - 3.2. Define the IP address of the system on which the SNMP Trap Receiver runs.
 - 3.3. Selecting the Trap Receivers SNMP Version.
 - 3.4. Set the Trap Receiver Port.

The image shows a configuration window titled 'SNMP Trap Alerts'. It contains the following settings:

- 'Enable 1st Trap Receiver' is checked (toggle switch is green).
- 'Trap Receiver 1 IP Address' is set to '192.168.11.159'.
- 'Enable 2nd Trap Receiver' is unchecked (toggle switch is grey).
- 'Trap Receiver 2 IP Address' is set to '192.168.11.23'.
- 'Trap Receivers SNMP Version' is set to 'SNMPv3'.
- 'Trap Receiver Port' is set to '5555'.

 At the bottom of the window are 'Update' and 'Reset' buttons.

- Click on the **Update** button when done. Once you click the update button, the Base Unit will reboot and will start sending SMS trap alerts.



Above shows the SNMP Trap as received by iReasoning MIB Browser

6.3 JSON (PULL)


To integrate using JSON, We just have to type in the URL the following extensions along with the IP address of your gateway.

http://IP_ADDRESS/probe_list.json

This call returns the list of sensor probes connected to the Base Unit and their settings.

Example:

http://192.168.1.1/probe_list.json



http://IP_ADDRESS/probe_update.json

And this call returns the latest values of all the sensor probes.

Example:


http://192.168.1.1/probe_update.json

JSON	Raw Data	Headers
Save	Copy	
▼ probe_update:		
▼ 0:		
probe_id:	1	
probe_type:	0	
▼ status:		
0:	1	
1:	1	
▼ value:		
0:	30.65	
1:	30	
▼ 1:		
probe_id:	2	
probe_type:	19	
▶ status:	[6]	
▶ value:	[6]	
▼ 2:		
probe_id:	3	
probe_type:	1	
▶ status:	[3]	
▼ value:		
0:	29.01	
1:	51	
2:	19.2	
▶ 3:	Object	
▶ 4:	Object	

6.4 JSON (PUSH) with ADDON-LTE

With the use of our ADDON-LTE, we are now enabled to integrate into your IoT platforms.

Once we connect the LTE add-on into our base unit, we will have a new option for IoT under the settings menu.



Click on the IoT option and it will bring us to the set up page for our IoT integration.

The image shows a web form titled 'IoT Connectivity'. It has a toggle switch for 'Send Data to Cloud' which is turned on. Below this are input fields for 'URL', 'Device ID', 'Username', and 'Password'. There is also a field for 'Update interval' with a dropdown menu set to 'every' and a numeric input set to '0', with a 'min' label. At the bottom are 'Update' and 'Reset' buttons.

You can now input the URL where the data should go, the Device ID that will identify the gateway sending the data, Username and password for security and the update interval.

Note: Update interval has a minimum of 5 minutes

JSON structure is as follows:

```
{
  "t": "2020-02-21T05:20:33Z",
  "d": "000364037961",
  "u": "user",
  "p": "pass",
  "lo": "27.674",
  "la": "53.874",
  "nsg": "14",
  "nty": "3G",
  "nsi": "sim1"
}
{
  "t": "2020-02-21T05:20:33Z",
  "d": "000364037961",
  "u": "user",
  "p": "pass",
  "sensors": [
    {
      "si": "1",
      "sn": "Int. Temp1",
      "st": "Int. Temp",
      "sv": "24.40"
    }
  ]
}
{
  "t": "2020-02-21T05:20:33Z",
  "d": "000364037961",
  "u": "user",
  "p": "pass",
  "sensors": [
    {
      "si": "2",
      "sn": "Int. Ping1",
      "st": "Int. Ping",
      "sv": "1.00"
    }
  ]
}
...
{
  "t": "2020-02-21T05:21:36Z",
  "d": "000364037961",
  "u": "user",
  "p": "pass",
  "IOs": [
    {
      "si": "9",
      "sn": "UndefinedIO 1",
      "st": "Dry Contact",
      "sv": "0"
    }
  ]
}
```

t = is the timestamp in UTC

d = is the device ID

u = is the username

p = is the password

The first call is the connectivity details:

lo: longitude from GPS

la: latitude from GPS

nsg: network signal strength

nty: network type 4G/3G/2G

nsi: sim used

```
"sensors": [
  {
    "si": "1",
    "sn": "Int. Temp1",
    "st": "Int. Temp",
    "sv": "24.40"
  }
]
```

This is the sensors structure:

si: sensor sequential identifier

sn: sensor name

st: sensor type


sv: sensor value

6.5 JSON (PUSH) with ADDON-LTE - Adding Webhook Endpoint

First, visit webhook.site and click on 'Your unique URL' then copy the URL.

The screenshot shows the Webhook.site interface. The main content area displays the 'Your unique URL' as `https://webhook.site/bb8ad622-1cd4-47f2-8c6f-2b759bc39a8d`, which is highlighted with a red box. Below this, the 'Your unique email address' is `bb8ad622-1cd4-47f2-8c6f-2b759bc39a8d@email.webhook.site`. The page also includes a 'REQUESTS' section on the left and a 'Request Details' section at the bottom.

After copying the URL, let's return to our IoT settings to input the credentials.



IoT Connectivity

Send Data to Cloud ☒

URL

https://webhook.site/bb8ad622-1cd4-47f2-8c6f-2b759bc39a8d

Device ID

00036403EA7D

Username

admin

Password

Update interval

every 5 min

Update

Reset

Above is an example input using the newly generated endpoint. The device ID, username, password and interval are all customizable.

webhook.site

Docs & API Custom Actions WebhookScript Terms & Privacy Support

Copy Edit New Login Upgrade

REQUESTS (49/500) Newest First

Search Query

POST #a8ccc

209.35.167.229

11/07/2023 6:57:41 PM

POST #b05d9

209.35.167.229

11/07/2023 6:57:39 PM

POST #8e000

209.35.167.229

11/07/2023 6:57:32 PM

POST #36888

209.35.167.229

11/07/2023 6:57:30 PM

POST #842a3

209.35.167.229

11/07/2023 6:57:28 PM

POST #c8de6

209.35.167.229

11/07/2023 6:57:26 PM

Request Details

Permalink Raw content Copy as

POST https://webhook.site/bb8ad622-1cd4-47f2-8c6f-2b759bc39a8d

Host 209.35.167.229 Whois Shodan Netlify Censys

Date 11/07/2023 6:52:53 PM (5 minutes ago)

Size 139 bytes

ID 57a08313-cd1d-4467-bc28-5884fcd02eea

Files

Query strings

(empty)

Raw Content

Format JSON Word-Wrap Copy

```
{
  "t": "2023-11-07T10:51:29Z",
  "d": "00036403EA7D",
  "u": "admin",
  "p": "admin",
  "IOs": [
    {
      "sl": "28",
      "sn": "UndefinedIO 4",
      "st": "Dry Contact",
      "sv": "0"
    }
  ]
}
```

Headers

content-type application/json

connection close

content-length 139

host webhook.site

Form values


(empty)

Go back to your browser where your endpoint is opened and results will start to populate.

Printed 2024 - Rev101 – Sensors Platform

80

6.6 XML output



The log can be accessed by appending *xmlOutput.xml* at the end of the Base Unit's IP address/FQDN as seen on the screenshot. More than the alerts, it also gives you the current status of the device. This option shows the latest 500 alert entries.

6.7 ModBus TCP / RTU

With the firmware 9.2 and above, Base Unit Modbus TCP can now be polled by 4 Modbus masters. For detailed instructions on Modbus usage, please refer to the dedicated manual available on our website or you may access it through the provided link below:
[Modbus Manual](#).

7 Sensor calibration

A unique feature of the InfraSensing Base Unit and external probes is that the Base Unit has a calibration feature available from the web interface. This feature allows to correct temperature and humidity readings based upon, for example a NIST Traceable measurement system.

To recalibrate the built-in or external probes, Go to Menu and then Settings.

Settings & Info

Device information	
Account name	admin
	Change Password
Current System Date	14 Feb 2019
Current System Time	01:02:05
	Update Time
Hardware Version	Release 5.1
Firmware Version	Release 8.00 (Feb 12 2019)
	Upgrade Firmware
Mac Address	00:03:64:03:44:40
IP Address	192.168.11.104
	Change IP
Node Status (online/used/max)	3/43/44
	Calibrate Sensors

Adjust your sensor readings by modifying the offset value (either + or -) and click on Update.

Note : Our sensors are pre calibrated by our manufacturer However we do offer our very own Calibration Certificate more information can be found here <https://infrasensing.com/lab/>**

Sensor Calibration

Sensor Type	Example Value	Operator	Offset value
InternalTemp	28.58 °C	<input type="text" value="+"/>	<input type="text" value="0.00"/>
ExternalTemp	? °C	<input type="text" value="+"/>	<input type="text" value="0.00"/>
ExternalHumd	? %RH	<input type="text" value="+"/>	<input type="text" value="0.00"/>
Fuel Level Max	?	<input "="" type="text" value="="/>	<input type="text" value="1023.00"/>
Fuel Level Min	?	<input "="" type="text" value="="/>	<input type="text" value="0.00"/>
Flow Rate Period (min)	5	<input type="text" value="-"/>	<input type="text" value="5"/>
Air Flow Threshold	?	<input type="text" value=">"/>	<input type="text" value="20.00"/>
Shock Threshold	?	<input type="text" value=">"/>	<input type="text" value="765.00"/>
Temp Threshold	0.00	<input type="text" value="-"/>	<input type="text" value="0.00"/>
Humidity Threshold	0.00	<input type="text" value="-"/>	<input type="text" value="0.00"/>
AC Voltage Type	<input checked="" type="checkbox"/> 220/240	<input type="text" value="110/120"/>	<input type="text" value="-"/>
AC Voltage Offset	?	<input type="text" value="+"/>	<input type="text" value="0.00"/>
Sync Internal Temp Sensor with External	<input type="checkbox"/>		
Thermal Emissivity (0.01-1)	<input type="text" value="0.95"/>		
Power Quality	<input type="text" value="230 Volts / 60 Hz"/>		
Reset 3-Phase Power Meter Counter	Reset Counter		
Reset Power Meter Total kWh Reading	Reset Reading		
Reset Tilt Sensor Values	Set to Zero Reset to Default		
Turn Panel Fan	On Off		
DC Power Control Sensor:			
Minimum(7-89) / Maximum(10-90) Voltage	<input type="text" value="-"/>	<input type="text" value="7.00"/>	<input type="text" value="48.00"/>
Minimum(0-89) / Maximum(0.1-90) Current	<input type="text" value="-"/>	<input type="text" value="1.00"/>	<input type="text" value="50.00"/>
Minimum Time to detect error (0-120s)	<input type="text" value="-"/>	<input type="text" value="10.00"/>	
Reset Counter	Reset Counter		

[Select CO2/VOC Reference Sensors](#)

[Update](#) [Reset](#)

With the introduction of firmware version 9.1, a new feature has been incorporated, allowing users to designate CO2/VOC sensors as reference points. For more information, refer to section 7.1.

7.1 Reference Sensors

Reference Sensor Selection" is a feature that offers the ability to designate a sensor as the reference point. Whether a CO2/VOC regular or daisy sensor is connected, a dropdown menu will appear to facilitate the selection of the reference sensor.

Select CO2/VOC Reference Sensors

Update

Reset

Reference Sensor Selection

CO2 Reference

VOC Reference

VOC Sensor2

CO2 Offgas Enable

VOC Offgas Enable

Update

7.2 Tolerance level

Flow Rate Period(min)	5	-	5
Air Flow Threshold	?	>	20.00
Shock Threshold	?	>	765.00
Temp Threshold	0.00	-	0.00
Humidity Threshold	0.00	-	0.00
AC Voltage Type	<input checked="" type="checkbox"/> 220/240	<input type="checkbox"/> 110/120	-
AC Voltage Tolerance	?	+	0
AC Voltage Value	-	-	220.00
Sync Internal Temp Sensor with External	<input type="checkbox"/>		

As you can see in the image above, you can also set the tolerance level (threshold) which is a parameter where in a trigger won't go off immediately if its within tolerance levels.

An example on how it is used is if you have an alert that would trigger at 30 degree Celsius and a tolerance set at "5" what happens is, if your actual temperature goes on to 30 degrees an alert would trigger and you would only receive a recovery alert or an "OK" status once the value goes down to 25 degrees as set on the tolerance level. That way, if in case the temperature goes down between

25.1 – 29.99 then goes back to 30 or above you won't get spammed with alerts or recovery emails or in a case where a device is set to turn on when the threshold is met and would turn off if not, you would avoid having that device to turn on and off countless times.


Note. Starting from firmware version 8.8 and above, there will be additional calibration options for SEC-TILT(Reset Counter) and ENV-THIMG(Thermal Emissivity) sensors.

Warning. For Thermal Emissivity calibration, it is recommended to be set to 0.95 or depending on the surface to be scanned with ENV-THIMG.Failure to calibrate may give off incorrect values for the ENV-THIMG sensor.


7.3 Threshold change and additional calibration functions

With the latest firmware update, you can now modify or configure the thresholds, you can access it using the following link format below:


(Base Unit's IP Address)/calibration2.html



Once you access the link, you will be prompted with this window which it will ask you for your username and password. By default the username and password is admin/admin



Upon logging in, you will be routed to the special calibration page. At the very bottom of the page you will be able to see the option for ENV-LHD.



RS485-GAS-VOC-H2

Thresholds:

Relay 1:

Relay 2:

Set Thresholds

Modbus Config:

Baudrate:

Parity:

Stop Bits:

Set Config

ENV-LHD

Resistance per Meter

Resistance

Set

Resistance Offset

Line 1

Line 2

Set

This is where you can set or adjust threshold to each sensor provided on this page.

8 Factory resetting of Base Unit

8.1 Base Units v1 and v2

Following only applies to Base Units v1 & v2 - the matching models are shown below



You can always hard reset the Base Unit to its default factory settings as follows. Resetting the device to factory default will result in all settings to be lost



1. Plug in power adapter or PoE cable
2. Within 2 seconds from plugging the power adapter or PoE cable, push the **Reset** button with a pen or similar and hold it for 5 seconds before releasing it.
3. Wait until the yellow LED doesn't blink anymore
4. Reconnect to the Base Unit's web interface at <http://192.168.11.160>

8.2 Base Unit v3 and v4

Following only applies to Base Units v3 and v4 - matching the picture below Kindly

note that due to a mistake in the boot loader of v3 units, the internal system specifications show it as a v2 unit. However, those are v3 units (or v4 for dual sensor probes) when they match the picture below.

You can always hard reset the Base Unit to its default factory settings as follows. Resetting the device to factory default will result in all settings to be lost



Remove the external sensor probe
Remove the power adapter or PoE cable
Push the **Reset** button
While the **Reset** button is pushed, plug in the power adapter or PoE Cable
After 10 seconds the Green & Yellow LED's will be on steady (not blinking)
Remove power adapter or PoE cable
Wait 3 seconds
Plug in power adapter or PoE cable
After a few seconds both Green & Yellow LED's are blinking
Reconnect to the Base Unit's web interface at <http://192.168.11.160>

8.3 Base Unit v5

Following only applies to Base Units v5

Resetting the device to factory default will result in all settings to be lost




1. Remove the external sensor probe.
2. Remove the power adapter or PoE powered network cable.
3. Push the **Reset** button.
4. While the **Reset** button is pushed, plug in the power adapter or PoE powered network cable .
5. Hold it for 15 seconds before releasing it. The yellow LED should be blinking fast.
6. Wait until the yellow LED is not blinking fast anymore.
7. On the LED display, the Base Unit will reboot. After a few seconds both Green & Yellow LED's should be flashing slowly.
8. While the PoE or power adapter is plugged in, push the **Reset** button.
9. Hold it for 15 seconds before releasing it.
10. On the LED display, the Base Unit will reboot. After a few seconds both Green & Yellow LED's should be flashing slowly.
11. The base unit will reset by loading to the firmware 3.2; it might not have an OLED display active
12. Reconnect to the Base Unit's web interface at **http://192.168.11.160** If you are unable to connect on that IP address then lookup the IP address of the device either from your DHCP server or using the Sensor Discovery Tool - <https://infrasensing.com/support/downloads.asp>

(Refer to section 2.8)

9 Add-Ons for the Base Unit

The Base Unit, the base unit, requires by default a network cable and 12v DC or POE power input. With the optional add-on modules, customers can add other network and power connectivity options to the base units.



9.1 Wifi Add-On

The InfraSensing Add on Wifi module is an expansion unit to the Base Unit which enables wired and wireless networking application. The Add on Wifi module supports 802.11n standards, and provides backward compatibility with older 802.11b/g standards as well. The up-to-150Mbps wireless speed makes it ideal for handling multiple data streams at the same time that ensures your network is stability and reliability



9.1.1 Features

Portable design

Connects directly to the Base Unit

Directly powers the Base Unit via the 12v DC adapter output GUI

accessible using any browser

USB support for 3G and LTE dongles

Pre-encryption that prevents unauthorized access from users outside of the network

It enables you to:

Add a Standard Wireless Router mode that creates an instant private wireless network to access and configure the Base Unit

Add an Access Point mode that creates a wireless network for Wi-Fi devices to access and configure the Base Unit

Add a client mode functionality that works as a wireless adapter for any Ethernet enabled devices to access and configure the Base Unit

Add an 3G and LTE USB data connection to your network when there is no ISP available

9.1.2 View of the Wifi Add-On connected to the Base Unit




9.1.3 Hardware interface



Interface	Description
ANT	Wireless antenna
ETH1	WAN/LAN port
ETH0	LAN port to Base Unit
DC IN	12-volt DC adapter socket
USB1	USB for 3G and LTE dongle

Powering the Add-On Wifi module with Base Unit

1. Connect the 12-volt DC adapter to the DC IN socket
2. Wait for the RED LED to turn solid
3. Connect the Base Unit to the Add on Wifi module via ETH0 and DC OUT



System requirements

PC with working LAN/WLAN interface
TCP/IP protocol installed on the PC
Web browser (Chrome, Firefox, IE, Safari etc.)
LAN cables (RJ 45)
RJ 45 male to female adapter for configuration via ETH0

9.1.5 How to access the Graphical User Interface (GUI)

We can access the GUI via WLAN and/or LAN connection. Configurations will be done on the GUI


As an access point (WLAN)

Power on the Add on Wifi module
Connect via Wifi to the unsecured SSID "ServersCheck"
Launch a web browser and type the default IP 192.168.1.1 to the address bar
By default there is no password that has been set
Username must always be "root"
Click LOGIN to access main menu page
Base Unit GUI will be available from the IP address on the OLED screen
Make sure that the Add on Wifi module and Base Unit has the correct IP range Setting the Base Unit to DHCP is recommended

LAN connection to PC (LAN)


The steps below apply to a Windows 7 system. For other systems (Windows, Mac, *Nix) steps are similar

Power on the Add on Wifi module
Connect ETH1 to the LAN port of your PC
Go to Network Panel > Network & Sharing Center
Click on **Local Area Connection** and then click on **Properties**. In the new window select **Internet Protocol Version 4** and click on the **Properties** button.




Set the corresponding IP ranges

We recommend setting it to 192.168.1.15 as shown below.
When done, click on the **OK** button.



Launch a web browser and type the default IP 192.168.1.1 to the address bar.
By default there is no password that has been set.
Username must always be "root".
Click LOGIN to access main menu page.



Base Unit GUI will be available from the IP address on the OLED screen.
Make sure that the Add on Wifi module and Base Unit has the correct IP range. Setting the Base Unit to DHCP is recommended


9.1.6 Username and password settings

Access the GUI.

By default there is no password that has been set.

Username must always be "root".

Click LOGIN to access main menu page.




Authorization Required

Please enter your username and password.

Username


Password




Go to System > Administration

Set and confirm password

Click SAVE and APPLY




There will be a notification that the password was successfully set



9.1.7 Configuration modes

Adding Internet connection to the Base Unit via ETH0 can be done with the following modes.

As wireless router



Access the GUI using WLAN
Go to Network > Interfaces
Edit LAN network



Go to Physical Settings tab and uncheck Ethernet adapter: eth1 (LAN)

Interfaces - LAN

On this page you can configure the network interfaces. You can bridge several interfaces by ticking interfaces separated by spaces. You can also use [VLAN](#) notation `INTERFACE.VLANNR` (e.g.: `eth0.1`).

Common Configuration

General Setup

Advanced Settings

Physical Settings

Firewall Settings

Bridge interfaces

☒

creates a bridge over specified interface(s)

Enable [STP](#)

☐

Enables the Spanning Tree Protocol on this bridge

Interface

☒

Ethernet Adapter: "eth0" ([lan](#))

☐

Ethernet Adapter: "eth1" ([lan](#))

☐

Ethernet Adapter: "eth2" ([usb4g](#))

☒

Wireless Network: Master "ServersCheck" ([lan](#))

☐

Custom Interface:

Click SAVE and APPLY
Go to Network > Interfaces
ADD NEW interface

Interfaces

Interface Overview

Network	Status
<div><div>LAN</div><div><div></div><div></div><div></div><div></div></div><div>br-lan</div></div>	<div>Uptime: 2h 26m 15s</div> <div>MAC-Address: C4:93:00:04:6B:44</div> <div>RX: 621.69 KB (7299 Pkts.)</div> <div>TX: 1.28 MB (7160 Pkts.)</div> <div>IPv4: 192.168.1.1/24</div> <div>IPv6: fda1:dd19:3d58::1/60</div>
<div><div>USB4G</div><div><div></div><div></div></div><div>eth2</div></div>	<div>RX: 0 B (0 Pkts.)</div> <div>TX: 0 B (0 Pkts.)</div>


ADD NEW INTERFACE...


Printed 2024 - Rev101 – Sensors Platform

97

Create Interface


Name of the new interface


 The allowed characters are: A-Z, a-z, 0-9 and _


Note: interface name length  Maximum length of the name is 15 characters including the null character


Protocol of the new interface Static address ▼


Create a bridge over multiple interfaces ☐

Cover the following interface ☐  Ethernet Adapter: "eth0" ([lan](#))

☒  Ethernet Adapter: "eth1" ([lan](#))

☐  Ethernet Adapter: "eth2" ([usb4g](#))

☐  Wireless Network: Master "ServersCheck" ([lan](#))

☐  Custom Interface:

Interfaces - ETH1

On this page you can configure the network interfaces. You can bridge several interfaces by ticking interfaces separated by spaces. You can also use [VLAN](#) notation INTERFACE.VLANNR (e.g.: eth0.1).




Common Configuration


General Setup

Advanced Settings

Physical Settings

Firewall Settings

Create / Assign firewall-zone ☐ lan: lan:   


☒ wan: usb4g: 

☐ unspecified -or- create: _____

Choose the firewall zone you want to assign to this interface


98

As an access point




Do steps 1 to 12 from Wireless Router configuration (section 9.1.7)
Connect ETH1 to any of the LAN port of the Router
Internet connection will be available on ETH0

As a Wifi client




Access the GUI using WLAN or LAN
Go to Network > Wifi
Do a SCAN for available Wireless networks



Join the desired Wifi network



Type the password for the Wifi network and uncheck the “replace wireless configuration”




Click SUBMIT
Internet connection will be available on ETH0

NOTE: The WIFI add-on serves as a router and designed for you to connect directly to the device, In the event that you want to integrate the device into your network it is indeed possible by having a network engineer configure the routing tables or protocols to be used for the connection.

9.2 Satellite Communication Add-On (ADDON-SATELLITE)




The add-on is used to send alerts via Satellite connection, it has global satellite coverage from pole to pole. Can be used as primary or back up connection enables you to receive alerts via email, SMS through space and has built-in GPS.




In order to use the add-on a monthly subscription through InfraSensing is required to connect the device onto the satellite network. Credits are required per message sent or received by the Base Unit

9.3 Industrial PoE+ Injectors +24 or -48v (ADDON-POE-24 / ADDON-POE-48)



Designed to support the deployment of our sensor platform in industrial environments operating on +24v DC and for the telecom industry, the telecom version PoE addon supports negative -48v DC as power input. This second generation of our DC Power Add-On has been modified so that we not just support our base units, but any PoE 802.3at enabled device. Up to 22 Watts.



9.4 LTE/2G/3G Communication Add-On (ADDON-LTE)

Designed to send alerts even when your IP network is down. Supports Global LTE/3G/2G connection and can send SMS alerts using your local micro SIM card. (Micro SIM + Data Plan required)



The addon features support for two(2) micro SIM cards. When the network on SIM1 fails, then automatically it will use the network of the backup SIM to send out the alerts and data.

The Cellular alerting addon has the Quectel wireless module embedded. This module has international carrier and regulatory approval as follows:

Carrier approvals: Deutsche Telekom(Europe), AT&T/Sprint/U.S. Cellular (North America), Telus (Canada)


Regulatory approvals: GCF (Global), CE(Europe) , FCC/PTCRB (North America), IC (Canada), Anatel (Brazil), IFETEL (Mexico), SRRC/CCC/NAL (China), KC (South Korea), NCC (Taiwan, China), JATE/TELEC (Japan), RCM (Australia & New Zealand), FAC (Russia), NBTC (Thailand), IMDA (Singapore), ICASA (South Africa)

Note:

The LTE add-on currently does not support cloud data upload and will automatically disable the cloud option when connected.

The LTE add-on is always in offline mode, and it only goes online when data is being sent. It will also disable the default SMS option of the base unit that uses premium credits. Also the add-on LTE,

The LTE addon can connect to the Base Unit or Sensorhubs (EXP-4HUB/ EXP-8HUB) in the same convention as our regular sensors.



9.4.1 GUI of the ADDON-LTE

To access the ADDON set up, login to your base unit and go to settings, under settings click Cellular Add-On

Settings & Info

Device information

Account name	admin
	Change Password
Current System Date	08 Feb 2020
Current System Time	01:49:43
	Update Time
Hardware Version	Release 5.1
Firmware Version	Release 8.20 (Feb 7 2020)
	Upgrade Firmware
Mac Address	00:03:64:03:6A:A4
IP Address	192.168.11.60
	Change IP
Node Status (online/used/max)	24/50/51
	Calibrate Sensors
	Cellular Add-On



ADDON-LTE Config

Primary mode



Backup mode



SIM1 PIN

SIM2 PIN

SIM1 APN

SIM2 APN

SIM1 APN Username

SIM2 APN Username

SIM1 APN Password

SIM2 APN Password

Add-on Status

Connected

Last Error

—

Network Status

Active SIM

SIM2

Network Name

GOMO GOMO

Signal Band

LTE

RSSI

14

IMEI

867698040182514

SMS Recipients

Append to SMS this text

Send test SMS

SMTP Server

SMTP Port

25

Secure connection

None

Use SMTP Authentication



SMTP Username

SMTP Password

From Email

To Email(s)

Email Subject

ServersCheck Sensor Alert

Append to Email this text

Send test Email

GPS Status

Fix

No fix

Satellites Found

0

Latitude

0.00000

Longitude

0.00000

Update

Reset

The Image above is the configuration page of the LTE addon and each section will be discussed further.

9.4.2 ADDON-LTE modes

There are two modes you can set your addon into, the Primary mode and the Backup mode. When set in “**Primary mode**” the add-on will primarily use the SIM’s data connection to send alerts.

ADDON-LTE Config

Primary mode

Backup mode

SIM1 PIN

SIM1 APN

SIM1 Username

SIM1 Password

SIM2 PIN

SIM2 APN

SIM2 Username

SIM2 Password

Add-on Status

Last Error

Network Status

Active SIM

Network Name

Signal Band

RSSI

MNO

SMTP Recipients

Append to SMTP this text

SMTP Server

SMTP Port

Secure connection

Use SMTP Authentication

SMTP Username

SMTP Password

From Email

To Email(s)

Email Subject

Append to Email this text

GPS Status

Fix

Subsides Found

Latitude

Longitude

Update

Reset

Connected

ADDON-LTE Config

Primary mode

Backup mode

SIM1 PIN

SIM1 APN

SIM1 Username

SIM1 Password

SIM2 PIN

SIM2 APN

SIM2 Username

SIM2 Password

Add-on Status

Last Error

Connected

Data connection failed

ServerCheck Sensor Host

Server test Email

No fix

0

0.00000

0.00000

When set in “**Backup mode**” the addon uses the SIM’s data connection to send alerts only when your network connection is unavailable. The LTE addon checks for the internal PING parameter to identify if your local Internet is down.

ADDON-LTE Config

Primary mode ☐

Backup mode ☒

SIM1 PIN

SIM1 APN

SIM1 Username

SIM1 Password

SIM2 PIN

SIM2 APN

SIM2 Username

SIM2 Password

Add-on Status: Connected

Last Error: --

ServerCheck Sensor Host:

Send test Email:

No. Tx: 0

Success Found: 0/0000

Latitude: 0.0000

Longitude: 0.0000

As shown on the image below the Internal ping is down, this will then signal the LTE add-on that the local network is down and will now use the SIM’s data connection to send alerts.

Sensors

Status	Type	Name	Value
<div></div>	Temperature	Int. Temp1	32.3 °C
<div></div>	Ping	Int. Ping1	2000 ms

PING Sensor

In Backup mode, the internal Ping is required to be enabled (Ping set-up is under **Section 3.2**) and ideally input an IP address or website outside of your local network with at least 60sec on the timeout counter like the example below.

Ping Setting

This optional PING sensor enables you to monitor if the IP network link is still reachable. You can check against an internal IP address to see if the internal network is still operational. If the device can connect to the internet, then you can also use a public IP.

Enable Ping sensor

Domain name OR IP address

www.serverscheck.com.

Ping timeout

60

sec

Update

Reset

Note: The LTE add-on does not provide Internet connection for your base unit and that data connection will only be used for sending alerts via the LTE addon configuration. With that in mind the Ping parameter will still be down until your local Internet is restored.

9.4.3 Setting up data connection

Data settings for your SIM include the APN, PIN, Username and Password. If any of the given are not applicable then we can just leave it blank.

Here is an example from T-mobile using the APN: fast.t-mobile.com (all other fields are blank since we only need the APN for T-mobile)

SIM1 PIN

SIM1 APN

fast.t-mobile.com

SIM1 Username

SIM1 Password

ADDON-LTE Config

Primary Mode

Backup Mode

SIM1 PIN

SIM1 APN

SIM1 Username

SIM1 Password

Add on Status

Last Error

Network Status

Active SIM

Network Name

Signal Band

RSSI

IMEI

SMS Recipients

Append to SMS this text

SIM2 Server

SIM2 Port

Secure connection

Use SIM2 Authentication

SIM2 Username

SIM2 Password

From Email

To Email(s)

Email Subject

Append to Email this text

GPS Status

Fix

Satellites Found

Latitude

Longitude

Network Status

Active SIM

Network Name

Signal Band

RSSI

IMEI

SIM1

T-Mobile

LTE

16

#5780907045234

SMS Recipients

Append to SMS this text

25

None

ServerCheck Server Host

No To

0

0.00000

0.00000

We suggest performing a test mail to make sure you have data connection and that your APN is correct (see section 4.1 for test mail)

here are other known APN's (subject to change depending on provider)

T-mobile - fast.t-mobile.com
AT&T for IoT devices - m2m.com.attz

The device has been tested to work with AT&T's network.

if you don't see your provider from the above please contact them for your APN settings

Setting up the Cellular Add-On device with AT&T

Prior to setting up, you will need a Prepaid or Postpaid ATT SIM card and the IMEI number of the device (this can be found in the lte.html page of the Base Unit, base unit).

ADDON-LTE Config

Primary mode: ☐ 3G ☒ 4G

Backup mode: ☐ 3G ☒ 4G

SIM PIN:

SIM APN:

SIM Username:

SIM Password:

Aut on Status: ☐

Last Error:

Network Status:

Active SIM:

Network Name:

Signal Band:

RSSI:

IMEI:

SMS Recipients:

Append to SMS this text:

Send test SMS:

SMTP Server:

SMTP Port:

Secure connection: ☐

Use SMTP Authentication: ☐

SMTP Username:

SMTP Password:

From Email:

To Email(s):

Email Subject:

Append to Email this text:

Send test Email:

SPS Status:

Pa:

Subscribes Found:

Latitude:

Longitude:

IMEI number shown on the illustration above.

To setup the device:

- Call AT&T to add the IMEI number to the SIM card. Any plan will work; you will not need a voice plan.
- For alerting you only need data (for email) and SMS can be purchased as an add-on.
- The IMEI number will need to be provided for the device to register on the network. You will need to tell AT&T that this is an "other" device and not a phone or modem
- Once the plan and IMEI number is associated with the SIM, ensure that the antenna is attached and to the GSM port on the add-on
- Once powered up, the initial registration on the network will take longer than the subsequent power on times
- The initial startup will take between 3-5 minutes and is normal
- Once the device is registered, the OLED screen on the add-on will have AT&T on the top line
- If the device does not register, power off the device, wait 60 seconds and reseal the SIM card and repeat the procedure, the registration can take up to three attempts depending on the availability of bandwidth on the network
- After registration, the subsequent power on instances will take between 45-60 seconds

Troubleshooting steps

- Ensure that the IMEI number is associated with SIM card for the plan to sync to the device
- A voice plan is not needed, it will simply need texting and data only. However, a voice plan associated will not cause any problems
- A prepaid SIM works as well as a postpaid SIM; the plan will not affect the ability for the device to work

9.4.4 SIM section

Following the data settings is the SIM information and SMS settings

ADDON-LTE Config

Primary Mode
Backup Mode

SIM PIN
SIM APN
SIM Username
SIM Password

Add-on Status
Last Error

Network Status
Active SIM
Network Name
Signal Band
RSSI
IMEI

SMS Recipients
Append to SMS this text

Send test SMS

SIM1
T-Mobile
LTE
16
86700001045204

SMS Recipients
Append to SMS this text

Send test SMS

SMTP Server
SMTP Port
Secure connection
Use SMTP Authentication
SMTP Username
SMTP Password

From Email
To Email(s)
Email Subject
Append to Email this text

GPS Status
Fix
Satellites Found
Latitude
Longitude

Update Reset

See section 8.4.7 on how to insert a SIM card and for alerting, see section 3.9

9.4.5 Email section

Next is the Email configuration field (Go to section 4.1 for setting up Email Alerts)

ADDON-LTE Config

Primary Mode
Backup Mode

SIM PIN
SIM APN
SIM Username
SIM Password

Add-on Status
Last Error

Network Status
Active SIM
Network Name
Signal Band
RSSI
IMEI

SMS Recipients
Append to SMS this text

Send test SMS

SMTP Server
SMTP Port
Secure connection
Use SMTP Authentication
SMTP Username
SMTP Password

From Email
To Email(s)
Email Subject
Append to Email this text

GPS Status
Fix
Satellites Found
Latitude
Longitude

Update Reset

SMTP Server
SMTP Port
Secure connection
Use SMTP Authentication
SMTP Username
SMTP Password

From Email
To Email(s)
Email Subject
Append to Email this text

Send test Email

9.4.6 GPS section

When you avail of the optional GPS feature you will have the information on the OLED screen of the LTE add-on as well as on the GPS section.

At the bottom most part of the Add-on settings we would see the optional GPS information as well as the update and reset buttons.

ADDON-LTE Config

Primary mode ☐ 3G ☒ 4G

Backup mode ☐ 3G ☒ 4G

SIM1 PIN: SIM2 PIN:

SIM1 APN: SIM2 APN:

SIM1 Username: SIM2 Username:

SIM1 Password: SIM2 Password:

App or Status: Connected

Network Status: SIM1: SIMART SIMART
LTS: 18
80798047102114

SMS Recipients:

Append to SMS this text:

SMTP Server:

SMTP Port:

Secure connection: ☐

Use SMTP Authentication: ☐

SMTP Username:

SMTP Password:

From Email:

To Email(s):

Email Subject:

Append to Email this text:

GPS Status

Fix: No fix


Satellites Found: 0

Latitude: 0.00000


Longitude: 0.00000

9.4.7 Inserting the SIM card into the LTE Add-On

1. Insert the SIM card(s) as shown in the image below(SIM card should be inserted all the way to the back).




Note: that for security reasons the only way to remove the SIM card is by using tweezers as shown on the illustration below.



2. Connect your ADDON-LTE into your base unit, initialization will start.




3. If SIM is inserted correctly the device will show that it has been detected and will start to register into your mobile network.



Note: That if it keeps on initializing and does not go to “Registering to network” then it means that the SIM card is not well inserted.



4. After the device successfully registers, it will have the default screen below showing the status of your ADDON-LTE.



5. If you have the optional GPS feature then please allow 5-10 minutes before the GPS signal is established.

6. Your ADDON-LTE will be ready for use, for SMS set up please go to section 3.9 and for email set-up go to section 3.2.

10 InfraSensing sensor probes

10.1 External sensor probes



InfraSensing uses external sensor probes for its environmental monitoring solution.

Only the power sensor requires a power adapter plugged into it; the power adapter's current sent to the sensor will be used to analyze the power state.

You can replace the shipped RJ45 cable with a custom standard RJ45 for a length of up to 10 meters or 33 ft between the Base Unit and an external probe. And can go longer with the use of CAT6/ CAT7 cables for up to 100m or 330 ft.

10.2 General instructions

The sensor should be connected as shown in the picture below. The RJ45-to-RJ45 cable goes from the external sensor probe into the bottom of the Base Unit using the RJ45 connector labeled **Serial** (for Base Unit v1, v2 & v3) Base Unit v4 or higher have 2 connectors for external probes labeled **Probe1** and **Probe2**



On the top you plug in your network cable connected to a switch and this into the RJ45 connector labeled **LAN/PoE**. If you don't have a PoE enabled network, then you will need the optional 12DC power adapter and plug it into the connector on top labeled **DC 12V**.



Important note: It is highly recommended to reboot the Base Unit after adding or removing any sensor probes for stability. Also, using incorrect power supplies or wrong PoE source may permanently damage the equipment and void the warranty.

11 THERMAL IMAGING SENSORS

11.1 Thermal Imaging Sensor (THIMG-XX)

The world's first SNMP & Modbus temperature monitoring sensor that tells you what it actually sees. 192(XS), 768(S), 4800(M), or 19200(L) temperature measurement points in one image, analyzed every 2 seconds.




THIMG-(XS/S)



THIMG-(M/L)


11.1.1 Installation of Thermal Image

Once the Thermal Sensor is plugged in, you should see a button on the gateway's GUI named "Thermal Camera" (firmware 8.0 and above). Once you click the option you will see the live feed of your thermal camera.



With firmware version 9, the Base Unit can connect up to 5 Thermal Imaging Sensors provided that they are connected to the high-speed ports (1, 2, 3, 4, and 7) of the SensorHub.

With the latest firmware version 9.1, the device is now capable of measuring thermal imbalances, which represent the difference between the highest maximum and lowest maximum temperatures.



Status	Type	Name	Value	Warning Range	Down Range	Repeat
	Temperature	Int. Temp1	26.69 °C	<18 OR >30	<15 OR >37	
	Ping	Int. Ping1	46 ms	>50	>60	
	Fault	Int. Fault1	FAULT	-	SET	
	Temperature	Ext. Temp2	13.49 °C	<18 OR >25	<15 OR >29	
	Temperature	Ext. Temp3	15.18 °C	<18 OR >25	<15 OR >29	
	Thermal Temp	Temp Min1	38.3 °C	<18 OR >25	<15 OR >29	
	Thermal Temp	Temp Max5	38.72 °C	<18 OR >25	<15 OR >29	
	Thermal Temp	Temp Min2	38.18 °C	<18 OR >25	<15 OR >29	
	Thermal Temp	Temp Max2	38.7 °C	<18 OR >25	<15 OR >29	
	Thermal Temp	Temp Min3	38.2 °C	<18 OR >25	<15 OR >29	
	Thermal Temp	Temp Max3	38.78 °C	<18 OR >25	<15 OR >29	
	Thermal Temp	Temp Min4	38.34 °C	<18 OR >25	<15 OR >29	
	Thermal Temp	Temp Max4	38.78 °C	<18 OR >25	<15 OR >29	
	Thermal Imbalance	Thermal Imbalance1	0.08 °C	>5	>10	

Thermal Imbalances = highest maximum - lowest maximum
Based on the image above the thermal imbalance is 0.08°C

NOTE: Due to transit or unforeseen events, in rare occasions the values of thermal camera sizes M and L are not displayed. This is possibly due to the sensor getting slightly loose. This is remedied by pressing down on the lens assembly in front of the case to reseat it in its socket.

Link : <https://infrasing.com/sensors/sensor-thermal-image-temperature.asp>

11.1.2 Adding Zones to the Thermal Imaging Sensor Camera

From firmware version 8.8, you can add zones within the thermal view page to specifically pinpoint the highest temperature recorded in each zone.

To add a zone, please follow these steps :

1. On the main screen, click Thermal Camera and you will be redirected to the thermal view page.
2. You can add up to 4 zone. To add a zone, simply highlight an area within the camera view.
3. Once done, click "Updated Selected Zones"

11.1.3 Delete Zones from the Thermal Imaging Sensor Camera

1. On the Thermal View, press middle-click (**scroll button**) on your mouse to delete a zone.
2. Once done, click "Updated Selected Zones"

11.2 Thermal Image Sensor (THIMG-SC)



The THIMG-SC is a compact thermal image sensor designed for switchgear, offering a comprehensive solution to monitor all bus bars with its 768 discrete temperature measurement points and 4 reporting zones.

It's mountable inside switchgear or onto existing IR windows, UL 61010 recognized, and integrates seamlessly via Modbus TCP or SNMP. Optionally available as an RS-485 sensor for direct integration with PLC and other systems, it provides flexible deployment options for efficient monitoring.

11.3 Industrial Infrared Spot Sensor (THIMG-STD-IRSPOT)



Works by capturing the emitted infrared radiation within a wide field of view (90°)



12 Gas Sensors

12.1 Ammonia (NH₃) Gas Sensor (GAS-NH₃)



Measures Ammonia in the air between 0 to 100ppm parts per million.

12.2 Carbon Dioxide (CO₂-NDIR) Gas Sensor (GAS-CO₂-NDIR)



Measures Carbon Dioxide in the air between 0 to 5000 ppm (parts per million).

12.3 Carbon Monoxide (CO) Gas Sensor (GAS-CO)



Measures Carbon Monoxide (CO) in the air between 0 to 1000 ppm (parts per million).

12.4 Chlorine (CL2) Gas Sensor (GAS-CL2)



Measures Chlorine in the air between 0 to 10 ppm (parts per million).

12.5 Ethylene (C₂H₄) Gas Sensor (GAS-C₂H₄)



Measures Ethylene in the air between 0 to 100 ppm (parts per million).

12.6 Ethylene Oxide (ETO) Gas Sensor (GAS-ETO)



Digital sensor designed for monitoring and measuring the level of Ethylene Oxide(ETO) in the ambient air.

12.7 Formaldehyde (CH₂O) Gas Sensor (GAS-CH₂O)



Measures Formaldehyde in the air between 0 to 10 ppm (parts per million).

12.8 Hydrogen (H₂) Gas Sensor (GAS-H₂-2)



Measures Hydrogen in the air between 0 to 100% LEL (lower explosive limit).

After powering the sensor through your Base Unit, the H₂ sensor needs 10 minutes to warm up.

Green -	less than 10% LEL
Orange -	10-50%
Red -	50%-100%
Magenta -	Greater than 100%

12.9 Hydrogen Chloride (HCL) Gas Sensor (GAS-HCL)



Measures Hydrogen Chloride in the air between 0 to 20ppm (parts per million).

12.10 Hydrogen Fluoride (HF) Gas Sensor (GAS-HF)



Measures Hydrogen Fluoride in the air between 0 to 10 ppm (parts per million)

12.11 Hydrogen Sulfide (H₂S) Gas Sensor (GAS-H₂S)



Measures Hydrogen Sulfide in the air between 0 to 100 ppm (parts per million)

12.12 Methane (CH₄) Gas Sensor (GAS-CH₄)



Measures Methane in the air between 0 to 100% LEL (lower explosive limit).

12.13 Methyl Mercaptan (CH₃SH) Gas Sensor (GAS-CH₃SH)



Measures Methyl Mercaptan in the air between 0 to 10 ppm (parts per million)

12.14 Nitric Oxide (NO) Gas Sensor (GAS-NO)



Measures Nitric Oxide in the air between 0 to 250ppm (parts per million)

12.15 Nitrogen Dioxide (NO₂) Gas Sensor (GAS-NO₂)



Measures Nitrogen Dioxide in the air between 0 to 20ppm (parts per million)

12.16 Oxygen (O₂) Gas Sensor (GAS-O₂)



Measures Oxygen in the air between 0 to 30% VOL

12.17 Ozone (O₃) Gas Sensor (GAS-O3)



Measures Ozone in the air between 0 to 5ppm (parts per million)

12.18 Phosphine (PH₃) Gas Sensor (GAS-PH3)



Measures Phosphine in the air between 0 to 2000ppm (parts per million)

12.19 Sulfur Dioxide (SO₂) Gas Sensor (GAS-SO₂)



Measures Sulfur Dioxide in the air between 0 to 20ppm (parts per million)

12.20 Sulfur Hexafluoride (SF₆) Gas Sensor (GAS-SF₆)



Measures SF₆ concentrations up to 1,000ppm (parts per million)

12.21 Refrigerant A1 (R-404A, R-22, and R-410A) Gas Sensor (GAS-A1)



Measures Refrigerant gas concentrations up to 10,000ppm (parts per million)

12.22 Refrigerant A2L (R-32, R-1234YF, R-1234ZE and R-454B) Gas Sensor (GAS-A2L)



Measures Refrigerant gas concentrations up to 10,000ppm (parts per million)

12.23 Refrigerant A3 (R-290) Gas Sensor (GAS-A3)



Measures Refrigerant gas concentrations up to 10,000ppm (parts per million)

12.24 Refrigerant (R-134a) Gas Sensor (GAS-R134a)



Measures Refrigerant (R-134a) in the air between 0 to 2000ppm (parts per million)

12.25 Gas Sensor Bump Test

We recommend to periodically test the operation of the gas sensor in critical environments. OSHA defines a bump test as “a qualitative function check in which a challenge gas is passed over the sensor(s) at a concentration and exposure time sufficient to activate all alarm settings.”

Required equipment:

1. Base Unit (BASE-XX)
2. Gas sensor
3. Bump test adapter (SPARE-GAS-GEN-BUMP)
4. Gas canister (from your local gas supplier)
5. Gas tubing (from your local gas supplier)


Note: For the amount of pressure, we can only apply up to 1000 PSIG.

Procedure:

1. Connect the Gas sensor to the Base Unit.
2. Next, connect the bump test adaptor to the gas sensor.
3. Attach one end of the tube to the adaptor.
4. Attach the other end of the tube to the gas cylinder source
5. Open the cylinder valve to apply gas until detected.
6. Stop applying gas by closing the cylinder valve.


13 Environmental Sensors

13.1 Temperature Sensor (ENV-TEMP)



Designed for indoor use inside data centers, server rooms and cabinets. Optional calibration certificates available.

13.2 Temperature & Humidity Sensor (ENV-THUM)



Designed for monitoring temperature and humidity levels inside data centers, server rooms, cabinets and other critical facilities. Humidity probe made in Switzerland.

Considerations for humidity sensor:

- Very dependent on air flow
- For rooms with different levels of air flows which is usually those in front of AC units and those that aren't, you can calibrate accordingly for more accurate results of ambient level and rack or other specific point levels of humidity

13.3 Magnetic Surface Temperature Sensor (ENV-TEMP-MAGNETIC)



The magnetic probe can be attached to any metal surface and measure its temperature.



13.4 Digital Sound and Noise level Sensor(dbA) (ENV-NOISE)



Designed for indoor use, this monitoring system ensures compliance with OSHA regulations and HCAHPS standards by accurately tracking and managing sound and noise levels.


Note: Detection for ENV-NOISE Takes up to 30 seconds before appearing on your interface.

13.5 Atmospheric Corrosion Sensor (ENV-CORROSION)



This non-intrusive plug & play corrosion sensor empowers users in mission-critical industries to effectively monitor atmospheric corrosion levels in real time and to compute the G level classification of the monitored infrastructure.


13.6 Differential Air Pressure and Temperature Sensor (ENV-AIRPRESSURE)



Designed in the USA for monitoring differential air pressure and air temperature in data centers, server rooms, healthcare facilities and other critical facilities. Pressure and temperature sensors are made in Switzerland.

13.7 Linear Heat Detection Sensor (ENV-LHD)

Digital sensor that uses the linear heat cable. This sensor is capable of sensing heat anywhere along the cable and initiate an alarm once it's fixed activation temperature is reached. Unlike the linear heat cables, the senso device is not a fire safety device. It is a temperature limit detection device.



13.8 Optical Dust Sensor Probe (ENV-DUST)


Air Quality (dust) is an invisible threat to Data Centers, server rooms, equipment rooms, telecom shelters, also Haze due to forest fires or fossil fuels is a common source of dust particles. Typically air-conditioning units can purify the air but when high peaks of pollution are reached, then they may no longer cope. Dust deposits on circuit boards can damage it. This may result in permanent loss of IT equipment such as servers, network and storage systems.

Our sensor is designed to monitor dust particles in data centers, server rooms & cabinets.



13.9 Particle Sensor (ENV-PARTICLE)

Designed to provide added value to applications in several industries, including air quality monitoring air purifiers and HVAC.



13.10 Water Leak Sensor (ENV-WLEAK-COMBO5M)

*Fuel and battery cables are also available and all cables can be expanded up to 200m or 660ft (ENV-FLEAK-COMBO and ENV-BLEAK-COMBO)



IMPORTANT NOTICE FOR WATER / FLOODING SENSORS

The flooding / water detection sensor consists of 2 parts: the sensor (gray box with InfraSensing label on it) and the yellow water sensing cable (shown left). **Only the yellow cable may be submerged** – this is the water sensitive part of the sensors! The sensor probe (gray box) has to be kept at all times above the water level.

Should you need to pinpoint the exact location of the leak, then we also have a Water leak location module. (ENV-WLEAK-LOC-COMBO5)

13.11 Optical Oil & Hydrocarbon Leak Sensor (ENV-LEAK-OPTICAL)



A reusable, contactless sensor designed to detect liquid hydrocarbon presence on surfaces. Utilized optical sensing to monitor hydrocarbon leaks with the option for calibration to detect surface area.

13.12 Stainless Steel Temperature Probe (ENV-TSTAIN)



The Stainless Steel Temperature monitoring probe was designed to monitor temperature in area's where the other InfraSensing sensors can't be used,

13.13 Extreme Low Temperature Sensor (ENV-TULTRA)



This sensor was designed to monitor temperature in applications where our traditional temperature sensors can't be used. With its IP 66 rated enclosure and stainless steel protected platinum sensor head, this sensor can be used in extreme low temperature environments of up to -200°C (-328°F)

13.14 Industrial Surface Temperature Sensor (ENV-TSURFACE)



Industrial digital SNMP & Modbus TCP sensor designed to be attached to a cable or pipe and monitor its temperature.

13.15 IP rated sensor assembly (leak, industrial probes, etc.)

Out from the box, for the Ethernet connector, you should have the 3 parts that are yet to be assembled: the over-nut, rubber gasket, and contracting gland (from left to right).



To get started, insert the over-nut and rubber gasket in your LAN cable then plug it in on the protruding RJ 45 connector from the sensor probe.




Once that's done, insert the rubber gasket all the way inside the over-nut.



After that, connect them both on the RJ 45 connector of the sensor.



Now that we have that, we just need to insert the contracting gland to seal the Ethernet passthrough. Your stainless steel temperature sensor should now look similar to the following image.



13.16 Water Spot Detection Sensor (monitors a specific spot) (ENV-WSPOT)



The water spot sensor is used in applications where the water leak sensor can't be deployed. Detects water from the location where it is placed wherein water makes contact to the 2 rods.

Note: Once an alert is triggered using our water spot detection sensor, make sure the metal prongs are dried before reusing.

13.17 View of the Airflow Sensor (ENV-AIRFLW)



The displayed side will be the one where the air should be allowed to flow. As an example, on an environment where floor cooling is utilized, the implementation would be similar to the figure:



As we're utilizing floor cooling on this example, the side where the air should flow is placed facing downwards to detect the airflow it should have.

14 Daisy Chain



This icon represents sensors with the optional Daisy Chain Version.

Please upload the special firmware to your Base Unit (BASE-XX) for the daisy chain sensors to work. You may download the firmware here [Daisy Chain Firmware](#)

Please refer to **section 2.11** on how to properly upload the firmware.

14.1 Daisy Chain Temperature Sensor (DAISY-TEMP)



Designed for monitoring temperature and humidity levels inside data centers, server rooms, cabinets and other critical facilities. Offers optional calibration certificates. With a streamlined setup requiring only one IP address for every daisy chain, it can seamlessly connect up to 15 DAISY-TEMP sensors.

14.2 Daisy Chain Temperature and Humidity Sensor (DAISY-THUM)



Designed for monitoring temperature and humidity levels within critical facilities such as data centers, server rooms, and cabinets. Also, has the capacity to connect up to 15 DAISY-THUM sensors.

14.3 Daisy Chain Infrared Spot Sensor (DAISY-THIMG-IRSPOT)




Industrial digital SNMP & Modbus TCP sensor designed for contactless temperature monitoring inside enclosures. The sensor returns the average temperature of everything within its field of view. Can connect up to 20 THIMG-DAISY-IRSPOT sensors per daisy chain and only 1 IP address required for every daisy chain.

14.4 Daisy Chain Temperature Magnet Sensor (DAISY-TEMP-MAGNET)




This sensor was designed to monitor temperature in applications where our traditional temperature sensors can't be used. The magnetic probe can be attached to any metal surface and measure its temperature and has a high temperature silver plated shielded wire with strong magnetism and strong absorption.

14.5 ISO 17025 Calibrated Cylindrical Daisy Chained Temperature & Humidity Sensor (DAISY-THUM-C)



Plug & play sensor designed for monitoring temperature & humidity inside racks and hot/cold aisles in data center white spaces. Also, has the capacity to connect up to 20 DAISY-THUM-C sensors. With an optional RS-485 (Modbus RTU) output.

14.6 Daisy Chain Start (DAISY-STARTER)



The DAISY-STARTER serves as the controller for the daisy-chained sensors. It is required for all our daisy chain sensors.

Note:

The DAISY-STARTER cannot be connected to Sensorhub (EXP-8HUB) and Multi-Sensor & Hub (EXP-4HUB)

Only one DAISY-STARTER can be connected to one Base Unit (BASE-XX).

14.6.1 Connecting Daisy Chain Sensor

The ports on DAISY-STARTER and DAISY SENSORS are labeled “**IN**” and “**OUT**”. This is to ensure that you are connecting each device accordingly. See images below for reference.

DAISY-STARTER




DAISY-THUM



Images above shows the IN and OUT ports labeled on your sensors.

Before proceeding, it's important to prepare all the necessary devices. Ensure that you have both the BASE-XX and DAISY-STARTER devices on hand. Keep in mind that each BASE-XX can only connect to one DAISY-STARTER. In the example below, we used DAISY-THUM SENSOR.



First, connect your BASE-XX to your DAISY-STARTER using a regular RJ45 cable. Refer to the image below for reference :




Once you have connected the BASE-XX and DAISY-STARTER, it's time to connect the DAISY-THUM sensor. Begin by locating the OUT port on the DAISY-STARTER and the IN port on the DAISY-THUM sensor. These ports are typically labeled for easy identification.

Next, take a regular RJ45 cable and connect one end to the OUT port on the DAISY-STARTER and the other end to the IN port on the DAISY-THUM sensor. Ensure that the cable is securely plugged in on both ends to establish a stable connection. Please refer to the image below for reference.

Take care not to force the cable into the ports, and avoid pulling on the cable once it is connected. Once the connection is established, you're ready to move on to the next step.

NOTE: The port near the led indicator is always the OUT port. Even you have a label that would say IN, but it's near the led indicator, that would basically be the OUT port.



Using a regular RJ45 cable, connect the OUT port of the first sensor to the IN port of the next sensor. Keep repeating this process until all of your sensors are connected.


NOTE: Up to 15 daisy sensors per base unit within 100m/330ft of total length Longer distances possible with optional DAISY-BOOSTER



DAISY-THUM SENSOR

Now that all of your sensors are connected, it's time to power up your Base Unit. You have several options for powering your device:

1. POE (Power over Ethernet): You can power your Base Unit directly through the Ethernet cable.
2. BASE-PWR: You can also use power adapter to plug your Base Unit directly into an electrical outlet.
3. BASE-PWR-USB: If you don't have access to an electrical outlet, you can power your Base Unit using a USB cable connected to a computer or other USB-enabled device.



Note:

The Base Unit and Daisy Chain Start connecting cable should not be more than 2 meters (6.6 ft.) in length. Additionally, the total length of the daisy chain, including the Daisy Start and Gateway, should not exceed 100 meters. However, if you require a longer distance, you may extend the daisy chain with the use of Daisy Booster.

Now that you have everything set up and your Base Unit is powered on, you can access it by obtaining the IP address displayed on the device. To do this, check the device manual or packaging for instructions on how to find the IP address.

Once you have the IP address, enter it into your web browser to access the Base Unit's user interface. From there, you can view and manage your sensors and configure settings for your system.



If you have daisy-chained sensors, you may see a new menu that displays all of your connected sensors. Refer to the image below for an example of what this menu might look like.

Sensors

Status	Type	Name	Value	Warning Range	Down Range	
	Temperature	Int. Temp1	17.99 °C	<18 OR >37	<15 OR >41	
	Temperature	Daisy Sensor1	18.65 °C	<18 OR >25	<15 OR >29	
	Humidity	Daisy Sensor2	51.29 %RH	<45 OR >65	<40 OR >70	
	Temperature	Daisy Sensor3	18.49 °C	<18 OR >25	<15 OR >29	
	Humidity	Daisy Sensor4	51.95 %RH	<45 OR >65	<40 OR >70	

Daisy Chain Information

PING Sensor

Fault Sensor

To identify the chained sensors in your Daisy chain, simply click on the “Scan for connected Daisy Chain Sensors” option. This will prompt your Gateway to perform a scan, which typically takes less than a minute. If you need to scan again, you may click on the same button after one minute.

Daisy Chain Sensor Config

No.	Status	Serial	Name	Type
1		DSS-TH004587	Daisy Sensor1	Temperature
2		DSS-TH004587	Daisy Sensor2	Humidity
3		DSS-TH004046	Daisy Sensor3	Temperature
4		DSS-TH004046	Daisy Sensor4	Humidity

Scan for Connected Daisy Chain Sensors

Scan for Connected Daisy Chain Sensors

14.7 Daisy Booster



The DAISY-BOOSTER extends the operating length of the daisy chain sensors from 100 meters up to 200 meters. It is connected between 2 sensors on the daisy chain for those applications where the standard total length of 100m/300ft for a daisy chain is too short.

You can add a DAISY-BOOSTER anywhere on your daisy chain. When adding a booster, be sure to pay attention to the color indications to ensure that it is properly connected. It has a led to show optimal placement of DAISY-BOOSTER.

Color Indicator :

- Red

The placement of the Daisy Booster is not optimal
- Yellow

The placement of the Daisy Booster is fairly good
- Green

The placement of the Daisy Booster is optimal

15 Power Sensors

15.1 View of DC Voltage Sensor Sensor (12-80V) (PWR-DC-VOLT)

DC voltage measurement & failure monitoring sensor. Designed for industrial +24v environments and -48v telecom infrastructure..



15.2 View of Current Sensor (PWR-AC-CUR)




Connecting the Current Sensor

1. Just plug the sensor to your gateway via Ethernet cable.
2. Make sure you place the current clamp correctly as shown below.


Example Plug going to the wall outlet



Make sure you separate the wire as shown on the image below
You do not have to peel the protective rubber covering the wire but make sure that the two wires are separate.



Clamp the transducer on either of the wires and check if you have reading over the gateway GUI.



15.3 View of AC power failure (PWR-AC-FAIL)

The power failure sensors enable you to get alerts when the main power goes out.



Almost any server room is equipped with UPS systems (batteries) that kick in when the main power supply goes out. However knowing when this occurs is a different thing. While the more expensive UPS systems have some kind of management and alerting system, the most popular ones don't have it.

The power failure sensors from enable you to get alerts when the main power goes out as well as measure the actual voltage.

In combination with our PWR-AC-CUR, you can measure power more accurately.

15.3.1 Main sensor unit (PWR-BAT-STRING)



Main unit for the battery monitoring system where the battery cell sensors as well as the string current sensor are connected.

Sensor Units (PWR-BAT-CELL)



Note:- for Li-Ion batteries monitor for following toxic gasses: Hydrogen Fluoride (HF), Carbon Monoxide (CO) or Carbon Dioxide (CO₂)

- For lead acid batteries the primary gas to monitor is the Hydrogen gas (H₂). Monitoring up to 100% Lower Explosive Limit (LEL).

The gas detectors can be optionally mounted onto the PWR-BAT-STRING module or can be purchased as separate gas sensors.

You can chain connect up to 15 PWR-BAT-CELL for every PWR-BAT-STRING.


15.4 Power Quality Sensor (PWR-AC-QUAL)



Using industry standards, it will analyze and translate your power quality in simple and actionable information.

Plug and play. Simply connect an IEC C13-C14 cable to the unit and into the power wall outlet you want to monitor. As soon as it is powered, it starts monitoring. It is that simple.

It is designed to monitor single-phase power quality in your critical facilities and edge infrastructure sites.



15.4.1 Initial set up for the power quality sensor using BASE-XX

1. Connect your power quality sensor into your power outlet using an IEC C13-C14 cable, then via Ethernet cable going into your Base Unit.

	Volt	Volt Meter1	198.4 V	<46 OR >250	<44 OR >300	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	-
	Voltage Status	Voltage Status1	BROWNOUT	-	SET	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	-
	THD	THD1	1.1 %	>5	>15	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	-
	Frequency	AC Frequency1	60.08 Hz	<50 OR >60	<40 OR >70	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	-

2. Access your Base Unit, the above image should be visible from your homepage, now we have to set up the correct reference voltage, to do this we have to go to Settings>Calibrate Sensors

Temp Threshold	0.00	-	0.00
Humidity Threshold	0.00	-	0.00
AC Voltage Type	<input checked="" type="checkbox"/> 220/240	<input type="checkbox"/> 110/120	-
AC Voltage Offset	?	+	0.00
Sync Internal Temp Sensor with External	<input type="checkbox"/>		
Power Quality	230 Volts / 60 Hz		

Update Reset

3. Under the Calibration option, just scroll down until you see the option for Power Quality, then apply the correct Voltage reference. The power quality sensor would also sync its time with Base Unit upon updating the calibration option.

Although you can fully customize the alerting parameters, we recommend the table below as your guide.

State	Description	Actual V	Voltage Threshold	Duration
OK		Within +/-6%	+/-6% from reference	
Warning	SAG	Low voltage	- 6% from reference Voltage	0 to 1min
Down	BROWNOUT	Low voltage	- 6% from reference Voltage	> 1min
Warning	SWELL	High voltage	+6% from reference Voltage	0 to 1min
Down	LONG SWELL	High voltage	+6% from reference Voltage	> 1min
Down	INTERRUPTION	Zero Voltage	Voltage is zero	< 5 sec
Down	FAILURE	Zero Voltage	Voltage is zero	>= 5 sec
Down	TRANCIENT	Sudden Spike	>30%	Few milliseconds (lightning, etc.)

15.4.2 Initial set up for the power quality sensor using SD card .ini file

1. Connect your power quality sensor into the power outlet using an IEC C13-C14 cable, then connect it to the PC using the USB Type-B to USB cable.
2. Access then SD Card using your PC's file explorer, then open the .ini file. The .ini file contains the parameters that are used by the PWR-AC-QUAL.
3. In the .ini text file, change the following:

Parameter	Value
"VOLT_DEFAULT"	230
"F_DEFAULT"	60
"SET_TIME" <ul style="list-style-type: none">• After you have enabled this option, set the YEAR, MONTH, DAY, HOUR, MIN, and SEC according to the current timestamp.	YES

Sample file:


```
"RELEASE"          3.00
"DATE"             Sep_25_2019
"VOLT_DEFAULT"     230
"F_DEFAULT"        60
"CALIBRATED"       YES
"VOLT_OFFSET"      1
"VOLT_CODE100"     455300
"VOLT_CODE200"     912400
"SET_TIME"         YES
"YEAR"             2022
"MONTH"            02
"DAY"              03
"HOUR"             17
"MIN"              24
"SEC"              00
}
```

4. After the parameters are changed, save the file.


15.4.3 Ground (Earthing) Monitoring Sensor (PWR-GROUND)




The InfraSensing Grounding Monitoring system connects to your facilities or sites electrical ground system. It checks non-stop the grounding's resistance. This allows you to get early warning on your grounding system.



The above image shows our grounding sensor which checks the ground bar connected to the ground rod as well as the connectivity of 2 ground rods.



Ground bar connected to your Ground Rod



Ground rod connected to another ground rod

The above applications show that our sensor would continuously check if there are changes in your grounding system such as:

- accidental disconnected grounding systems
- corrosion of copper ground bars due to environmental conditions
- copper ground theft

Use solid/stranded wires with sizes 26-16 AWG to connect to the terminal blocks of the sensor.

15.5 IP68 Ultrasonic Fuel Level Sensor (PWR-FUEL)


15.5.1 Features

- Plug & Play
- Contactless (ultrasonic) fuel level measurement
- Operating distance of 0mm to 2000mm maximum
- Measures fuel level inside tanks with depths of up to 2m (6.5ft) with wall thickness of up to 6mm.
- Supports metal and plastic tanks
- Extremely low profile only 20mm high once mounted
- IP68 rates for outdoor use
- Calibrated in factory based on specs of your tank
- In operating temperatures of 4°C to 65°C (39F to 148F)
- ISO 8846 ignition protected
- Fire Resistance tested to ABYC, US Coast guard and ISO 10088 Industry standard SAE-5 stud mounting pattern with gasket seal and washers. Resistant to Petrol and Diesel


15.5.2 Maximum Tank Depths

- Operating distance of 0mm to 1100mm for Petrol tanks
- Operating distance of 0mm to 2000mm for Diesel tanks
- Operating distance of 0mm to 1500mm at 55°C
-

15.5.3 Dimensions



15.5.4 Mounting and installation



- The acoustic protrusion should be positioned in the tank aperture in the center of the hole. The protrusion should ideally be protruding into the tank and not be recessed in the hole. See drawing above.
- For tightening screws ensure base and washers are sitting flat. Tighten screw until screw head makes contact with the washer, and then tighten another 2 full turns.

Maximum torque for the mounting screws is 0.5 Newton meter.

Note: Drawing is not to scale. Please use the tank gasket as a template and make sure the tank hole is 42mm .


15.5.5 Tips and example installations

- The sensor must not be mounted closer than 150mm from the center to the sides of the tank, baffles or other intrusions.
- Only use on tanks greater than 200mm in depth.
- Sensor must be mounted parallel to the surface of the liquid.
- Make sure that sensor protrusion is NOT in contact with any object including Sealants when mounted.
- Use gasket and fittings as provided.
- Mount above deepest point of the tank.

Case 1


The sensor must be mounted at the deepest tank point!

It is recommended the sensor is mounted in the middle of the tank, this is particularly important on low or no baffled tanks that are mounted in moving vehicles or vessels. This allows the sensor to average waves of fuel to the correct level when the depth is varying due to wave slop.




Case 2

The sensor must be mounted at least 150mm from a vertical tank baffle, tank walls and piping.




Case 3


Use 5 washers provided, washers must be placed under screw heads to prevent rubber lid damage.




Case 4
Acoustic protrusion must not touch the tank frame.



Case 5
The sensor must be mounted so it can see the bottom of the tank if the fuel is to be measured to the bottom.




Case 6
Inlet and Outlet piping must go in at least 2/3rds of the way in to the tank to stop turbulence when filling.




Case 7

Do not fit the sensor with a tube.




Case 8

Ensure bolts and mounting holes are aligned properly to keep plastic body isolated acoustically from tank.
Do not over tighten the screws.



16 Industrial sensor

16.1 Industrial 0-10V (IND-0-10V)




Designed to read any 3rd party sensors that has output of 0-10V.
Can power up sensors with auxiliary 12V DC supply.

16.2 Industrial 4-20mA (IND-4-20mA)



Designed to read any 3rd party sensors that has output of 4-20mA.
Can power up sensors with auxiliary 12V DC supply.

16.3 The IO Sensor Probe – 16 Dry Contacts IN & 4 OUT (IND-IO)



16.4 General description

The IO sensor probe is a 16-zone expander for the Base Unit that adds up to 16 dry contacts for sensor alarm detection and indication. It has 4 output lines that can drive sirens and strobe lights. It is also capable of giving a 12-volt power supply and a maximum of 700 mA current capacity, enough to power several sensors and output devices.

Note: Only one IO Sensor Probe per Base Unit with no other sensors connected, It needs to be directly plugged in one of the ports (does not work with expansion hubs)

16.5 Applications

- SNMP interface sensor trigger and status
- SNMP traps sent when a change of state occurred
- SNMP polling for zone/sensor status
- SNMP set capability for OUTPUT purposes
- 12-VDC power source for sensors


16.6 Terminal description

TERMINAL BLOCKS


DI1 to DI16 : 16 digital inputs
DO1 to DO4 : 4 digital outputs
+12V : 12 VDC supply
GND : supply ground

16.7 Basic wiring diagram


Inputs: if sensors are getting their power supply from the IO sensor probe



Inputs: if sensors are getting their power supply from an external source or internal battery



Outputs: to drive a siren, lamp/strobe or any output device



16.8 Base Unit IO sensor probe interface

Status	Type	Name	Value	Warning Range	Down Range
	Temperature	Int. Temp1	29.42 °C	<div>< 18</div> <div>> 37</div>	<div>< 15</div> <div>> 41</div>
	Input 1	Undefined 1	OK	<div>alert if contact state is not</div> <div>Open</div>	<div>for more than</div> <div>500</div>
	Input 2	Undefined 2	OK	<div>alert if contact state is not</div> <div>Open</div>	<div>for more than</div> <div>500</div>

Control Outputs

Name	Current Value	Default State	Control Output
Output1	OFF	OFF	CYCLE
Output2	OFF	OFF	CYCLE
Output3	OFF	OFF	CYCLE
Output4	OFF	OFF	CYCLE

Name

- Is used to assign a name to a zone or sensor (i.e. motion1, smoke1, door1)
- Due to memory limitations, make sure that the maximum number of characters on this field doesn't exceed 31.

Value

- Shows the status of a zone. OK = normal condition, **Trig** = a zone/sensor has been triggered

Time (milliseconds)

- A time period that can be set which serves as a "wait period" before the IO sensor probe considers a change of state of a zone/sensor as an alert or a trigger

Normal State

- This will set the "logic" of the Input on how to define a trigger /change of state coming from the sensors
- It can be set as "open" for normally open (NO) logic or "closed" for normally closed (NC) logic.

ALWAYS CLICK "UPDATE" AFTER EVERY CHANGE IN VALUES/PARAMETERS for changes to take effect

OUTPUT1 TO OUTPUT4

- The default state can be set to either ON or OFF and is used in conjunction with triggers (ex. siren or strobe /lamp)
- CYCLE button is used to switch the button on and then off or vice versa depending on the default state.


16.9 Wiring configuration and settings (anti tampering)

The IO sensor probe does not have the ability to give out specifically a “tamper” alert. But it can be wired and set to give out a “normal” alert.


If ever a power supply wire or a signal wire was cut off in which case the monitoring team must still attend to.

Basic wiring diagram for Inputs still applies

Inputs: if sensors are getting their power supply from the IO sensor probe




Inputs: if sensors are getting their power supply from an external source or internal battery



A typical sensor (motion, smoke, CO, etc.) has dry contacts as its signal output to a control panel (usually located inside of the sensor, at the back or already exposed via 3 wires and a terminal connector)

Connect the signal wires from the IO sensor probe (can be interchanged) to NC and C terminals of the sensor



DRY CONTACT TERMINALS

NO: normally open (open circuit if not triggered / short circuit when triggered)

NC: normally closed (short circuit if not triggered / open circuit when triggered)

C : common (common terminal)

Set the all Normal State to **“Closed”** (setting the trigger logic to normally closed)

IMPORTANT NOTICE WHEN MONITORING VIA SNMP

When monitoring the IO Sensor via SNMP then one should use the SNMP traps feature instead of using the SNMP Get requests. Through SNMP GET one only receives the status of the contact at the time when the request is made. With the SNMP Traps it will trigger an alert as soon as the condition is met

16.10 Output triggering

The output triggering can toggle between automatic / assigned or manual/direct using the corresponding buttons on the sensor page. This requires firmware 6.00 or higher for the new Logic architecture.

Control Outputs

Name	Current Value	Default State	Control Output
Output1	OFF	OFF	CYCLE
Output2	OFF	OFF	CYCLE
Output3	OFF	OFF	CYCLE
Output4	OFF	OFF	CYCLE

Automatic/Assigned Output on Sensor Thresholds

The output triggering (digital and relay) can be set using the assigned threshold on a particular sensor. Simply assign an output from the drop down menu and its state you want it to do. Several sensors can share and be assigned to a particular output.

Status	Type	Name	Value	Warning Range	Down Range	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To
	Temperature	Int. Temp1	29.79 °C	< 15 > 37	< 15 > 41	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Output1 ON
	Input 1	UndefinedIO 1	OK	alert if contact state is not Open	for more than 500 ms	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Output2 OFF
	Input 2	UndefinedIO 2	OK	alert if contact state is not Open	for more than 500 ms	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Output3 CYCLE

****so to say after meeting a threshold, it can direct a device to either turn on or off****

17 Security Sensors

17.1 General description

InfraSensing’s security solution allows detection of doors, motion, and smoke. Underneath all of these security probes is a simple logic that’s adjustable to be close or open. Upon setting a given value, the sensor will instantly be triggered once the opposite is detected which will end up sending you an alert on the event that currently occurred. Being adjustable however, means there’s room for changes whenever the situation requires you. This allows for maximum flexibility of what defines an alert.


In this figure, the actual probe that’s attached is the door sensor with the logic defaulting to **CLOSE**. Upon opening, we see how it is triggered and thus will eventually send alerts depending on the alerting options chosen.

It is important to note that all security probes have the same web interface so it is advisable to attach one at a time and immediately rename it according to your naming conventions.



17.2 Door Sensor (SEC-DOOR)

The door contact sensor can be mounted inside racks, cabinets, or server room doors. It triggers an alert when the door is opened.



17.3 Motion Sensor (SEC-MOTION)



Industrial grade motion sensor feature digital signal analysis ensures consistent detection across its coverage pattern. With digital temperature compensation, it enhance catch performance at critical temperature levels, providing accurate detection of human IR energy over a wide temperature range.


Installation guide for motion sensor



As shown on the image, to remove the cover the lock should be pressed.



Once opened you should see 4 screws where you can connect the wires.



Red Wire: Connect to the Positive terminal (+12) of the Motion Sensor.

Black Wire: Connect to the Negative terminal or GND of the Motion Sensor.

Yellow or Orange Wire: Connect to the Common terminal (C) of the Motion Sensor.

White or Brown Wire: Connect to the Normally Closed (NC) Terminal of the Motion Sensor.


17.4 Smoke Sensor (SEC-SMOKE)



This sensor is a photoelectric smoke sensor that is designed to monitor smoke within facilities, complementing but not replacing mandatory building fire detection systems. It incorporates self-diagnostics and meets NFPA 72 Sensitivity testing requirements without external meters. Equipped with in-built dust compensation, sounder, and a patented CleanMe® feature, it ensures easy maintenance with a replaceable optical chamber. This sensor provides superior protection against false alarms from dust, RF, and ambient light through built-in drift compensation, enhancing its reliability.

17.4.1 Installation guide for Security Smoke Sensor

Wiring



There are 4 wires from the Security Sensor

1. Red Wire: Connect to the Positive terminal of the Smoke Detector.
2. Black Wire: Connect to the Negative terminal of the Smoke Detector.
3. Yellow or Orange Wire: Connect to the Common terminal of the Smoke Detector.
4. White or Brown Wire: Connect to the Normally Open Terminal of the Smoke Detector.

How to turn off alarm after smoke detection.

Disconnect the RJ45 cable connecting the smoke sensor from the Base Unit or SensorHub


17.5 Sound Sensor (SEC-SOUND)

With the data center demanding a very conducive environment for the services it provides, we know that the people making all those possible needs to be safeguarded as well from any anomaly-producing situations.

This sensor probe measures sound levels in decibels (dB) which allows you to be notified from a number of noise-producing deviations within your data center. Maximum level allowed is up to 100 dB.




17.6 Digital Luminosity Sensor (LUX) (SEC-LUX)




Industrial grade digital luminosity sensor measuring the ambient light in lux (lx).

17.7 Shock / Vibration Sensor (SEC-SHOCK)



This sensor can effectively detect and record tampering, movement, removal, or installation of equipment within racks, as well as monitor vibrations or shocks in rooms, particularly for sensitive equipment like traditional hard disks.

17.8 Tilt Sensor (SEC-TILT)



Digital SNMP & Modbus TCP sensor designed for monitoring and measuring tilt and levels in structures. The sensor is versatile, allowing installation, allowing installation in any orientation and presents values in degrees for precise monitoring.



18.2 Probe restrictions

- must not be connected with IO sensor probe
- must not be connected with wireless probe
- must not be connected with QoS probe
- Thermal camera and other sensors indicated should be connected to High-speed ports

Ports 1 to 4: High speed ports

Ports 5 to 8: Regular ports

18.3 Connecting the SensorHub to the Base Unit




The sensor hub connects through regular RJ45 cables to the Base Unit. The connection from the base unit going to the SensorHub should not exceed 1 meter / 3.3 ft.

Plug the 2 RJ45 cables in the 2 ports of the Base Unit and the other end going to the 2 ports of the SensorHub.

Do note that port label can be disregarded as long as 2 cables are connected, any combination would work, please refer to the image below.



18.4 Terminal connections




PROBE 1 AND PROBE 2:connect to Base Unit using two RJ 45 cables
PORT 1 TO PORT 8 : connect sensor probes

DI 1 to DI 4 :connect to 4 dry contact inputs
DO 1 to DO4 :connect to 4 digital outputs
NO, COM and NC :relay outputs

18.5 Basic wiring

INPUTS (dry contact) : same wiring diagram as the IO sensor probe for inputs
OUTPUTS (digital) : same wiring diagram as the IO sensor probe for outputs
OUTPUTS (relay) : connection to a load will depend on the wiring convention



relay terminals


NO: normally open(always open contact/not connected)

NC: normally closed(always shorted contact/connected)


C : common(common terminal)

18.6 Basic wiring diagram


INPUTS: If sensors are getting their supply from the EXP-8HUB



INPUTS: If sensors are getting their power supply from an external source or internal battery



OUTPUTS: To drive a siren, lamp/strobe or any output device



18.7 SensorHub web interface

When you access the Base Unit with the SensorHub Connected you can see the images below.

Expansion of probes along with Inputs along with a new option for outputs.

Sensors											Sub
Status	Type	Name	Value	Warning Range	Down Range	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To	
	Temperature	Int. Temp1	31.1 °C	<18 OR >37	<18 OR >41	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>
	Temperature	Ext. Temp1	25.55 °C	<18 OR >25	<18 OR >29	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>
	Security	Security1	Trap	Sensor Triggered		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>
	Temperature	Ext. Temp1	23.33 °C	<18 OR >25	<18 OR >29	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>
	Temperature	Ext. Temp2	26.65 °C	<18 OR >25	<18 OR >29	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>
	Shock	Shock1	0.87 G	<0.75 OR >1.25	<0.5 OR >1.5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>
	Input 1	Undefined0 1	OK	Close	for more than 500ms	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>
	Input 2	Undefined0 2	OK	Close	for more than 500ms	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>
	Input 3	Undefined0 3	OK	Close	for more than 500ms	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>
	Input 4	Undefined0 4	OK	Close	for more than 500ms	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	DISABLE	<input type="button" value="C"/>

Outputs

Control Outputs				Sub
Name	Current Value	Default State	Control Output	
Output1	OFF	OFF	CYCLE	
Output2	OFF	OFF	CYCLE	
Output3	OFF	OFF	CYCLE	
Output4	OFF	OFF	CYCLE	
Relay1	OFF	OFF	CYCLE	
Relay2	OFF	OFF	CYCLE	

We will discuss triggering outputs in the in section 19.1.


19 LoRa Wireless Hub and Node

By default our InfraSensing sensors are connected with an RJ45 cable to the base unit, But with the Wireless hub (EXP-LWHUB) and Node (NODE-LW-1P), any sensor can be connected wirelessly.

It works when we connect our wireless hub to our base unit (BASE-XX) then any of our sensor to one of the nodes, The node then transmits sensor data over a wireless communication protocol to the Wireless Hub.

The wireless protocol used is called LoRa, a long range and low power communication protocol in the free spectrum.


What you need:



19.1 Connecting and Pairing

Connect the Wireless Hub to the Base Unit via ethernet cable.

The Base Unit should be running firmware version 8.9.



Wireless LoRa should appear in the Base Unit GUI.

Sensors

Edit

Status	Type	Name	Value	Warning Range	Down Range	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To
<div></div>	Temperature	Int. Temp1	30.17 °C	<18 OR >37	<15 OR >41	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<div>DISABLE</div> <div>-</div>

On the Base Unit GUI, click on Wireless LoRa and you will be taken to the Wireless LoRa Configuration page.

Wireless LoRa Configuration						
Node No.	Status	Sensor Name	RSSI, dB	SNR	TX Power, dBm	
Pairing Status: Not Pairing						
<div>Start Pairing</div>						
LoRa Band			AU/AS (915-928 MHz)			
LoRa Channel			1			
<div>Update</div> <div>Reset</div>						

Setup your Band and Channel prior to connecting nodes. After choosing your desired band and channel, click on “Update”. Changing the band and channel will disconnect any previously connected nodes and re-pairing them would be required.

It is a good practice to keep adjacent hubs in different channels to avoid wireless congestion. Also, avoid using same LoRa channel to avoid any interference.

Wireless LoRa Configuration

Node No.	Status	Sensor Name	RSSI, dB	SNR	TX Power, dBm
Pairing Status: Not Pairing					

Start Pairing

LoRa Band: AU/AS (915-928 MHz)

LoRa Channel: 1

Update Reset

Note
Changing LoRa Band and/or Channel will delete Pairing and would need to re-pair the sensors.

NOTE:

When adding a new node to an existing group of paired nodes, please note that all previously connected nodes will also be unpaired and have to be repaired again. This is done by design.

To start the pairing process, on the Wireless LoRa Configuration page, click on “Start Pairing”. The LED on the LoRa hub will blink red and green which indicates pairing mode is active.

NOTE : The pairing status will also show “Pairing” when in pairing mode.

Wireless LoRa Configuration

Node No.	Status	Sensor Name	RSSI, dB	SNR	TX Power, dBm
Pairing Status: Not Pairing					

Start Pairing


LoRa Band: AU/AS (915-928 MHz)

LoRa Channel: 1

Update Reset

To pair a node, you would need to power it up and you will see the LED will blink red and green, it should stop before 5 seconds, that means that the node is paired successfully. If the LED stays ON for more than 10 seconds it would mean that the pairing failed and we would need to start over. To avoid a pairing miss we need to power and pair each node one at a time.

The node can be powered via 12v DC with a terminal block, 12v DC with a barrel jack for an AC/DC adapter, - 5v DC with a USB-C connector or 3x AAA batteries.



NOTE:

- You can pair the node even without a sensor connected.
- Up to 16 nodes can be connected

Click on “Stop Pairing” when done. Refresh the page and the list will populate with the connected nodes.

Wireless LoRa Configuration

Node No.	Status	Sensor Name	RSSI, dB	SNR	TX Power, dBm	
1			0	0	0	Apply
2			0	0	0	Apply
3			0	0	0	Apply
4			0	0	0	Apply
5			0	0	0	Apply
6			0	0	0	Apply

Pairing Status:

Start Pairing

Not Pairing

LoRa Band

AU/AS (915-928 MHz)

LoRa Channel

1



Update

Reset

Note
Changing LoRa Band and/or Channel will delete Pairing and would need to re-pair the sensors.

After pairing, the sensor connected to the wireless node should be ready to go.

To ensure no data is lost when transmitting, The minimum Polling Time for the Base Unit is 5 seconds when connected to a Wireless Hub.



Wireless LoRa Configuration

Node No.	Status	Sensor Name	RSSI, dB	SNR	TX Power, dBm	
1		Ext. Temp3 Humidity3 Dew Point3	-44	6	<input type="text" value="10"/>	<button>Apply</button>
2		Ext. Temp4 Humidity4 Dew Point4	-74	7	<input type="text" value="10"/>	<button>Apply</button>
3		Ext. Temp5 Humidity5 Dew Point5	-66	7	<input type="text" value="10"/>	<button>Apply</button>
4		Ext. Temp6 Humidity6 Dew Point6	-37	7	<input type="text" value="10"/>	<button>Apply</button>
5		Ext. Temp1 Humidity1 Dew Point1	-84	7	<input type="text" value="10"/>	<button>Apply</button>
6		Ext. Temp2 Humidity2 Dew Point2	-71	8	<input type="text" value="10"/>	<button>Apply</button>

Pairing Status:

Start Pairing

Not Pairing

LoRa Band

LoRa Channel

UpdateReset

Note

Chainging LoRa Band and/or Channel will delete Pairing and would need to re-pair the sensors.

Unpairing Nodes

To unpair connected nodes, click on “Start Pairing” then click “Stop Pairing”, this will disconnect all previously connected nodes on the hub. To start the pairing process again, please proceed to “Step 3 “ of this document.


20 Automatic & remote control of equipment

The built-in alerting enables you to be informed when a sensor exceeds defined thresholds or when an incident occurs. Some of these incidents could require an immediate action. For example, when the temperature is too high one may want to start a backup cooling unit; or when water is detected then start a pump.

With InfraSensing's infrastructure monitoring solution you can now also control devices: AC, relay or Dry Contact based. Devices can be controlled either by the Base Unit in an automatic way (condition based). In this section we will cover the automatic (condition based) control.

Requirement:

To use the control features you need a Base Unit with firmware 6 or higher and with an IO sensor or a SensorHub.



Both the IO sensor and the SensorHub feature dry contact outputs. However only the SensorHub feature relay outputs. AC powered devices can be controlled through an **external relay** which connects to a dry contact port on the SensorHub.

Important Notice:

The maximum capacity for the SensorHub's relay is 400VAC/150VDC and 200VA/192W. If an output device is to be used that exceeds those specifications, an external relay, i.e. solid-state relay, will have to be used.

20.1 Triggering outputs through the web interface

The output triggering can toggle between automatic / assigned or manual/direct using the corresponding buttons on the sensor page. This requires firmware 6.00 or higher for the new Logic architecture.

Control Outputs

Name	Current Value	Default State	Control Output
Output1	OFF	OFF	CYCLE
Output2	OFF	OFF	CYCLE
Output3	OFF	OFF	CYCLE
Output4	OFF	OFF	CYCLE
Relay1	OFF	OFF	CYCLE
Relay2	OFF	OFF	CYCLE

Automatic/Assigned Output on Sensor Thresholds

The output triggering (digital and relay) can be set using the assigned threshold on a particular sensor. Simply assign an output from the drop-down menu and its state you want it to do. Several sensors can share and be assigned to a particular output.

Status	Type	Name	Value	Warning Range	Danger Range	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To
	Temperature	Int. Temp1	26.78 °C	< 18 > 37	< 15 > 41	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Output1 ON
	Input 1	Underfloor C 1	OK	when if contact state is not Closed	for more than 500 ms	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Output2 OFF
	Input 2	Underfloor C 2	OK	when if contact state is not Closed	for more than 500 ms	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Output3 CYCLE

****so to say after meeting a threshold, it can direct a device to either turn on or off****

Let's for example configure a scenario where we want to trigger a backup air conditioning unit when the thresholds are exceeded.


Go to your temperature sensor and select the correct output and the state it should be in, as shown below

Status	Type	Name	Value	Warning Range	Danger Range	Repeat Alarm	Email	SMS	SNMP Trap	Set Output To
	Temperature	Int. Temp1	32.05 °C	<15 OR >35	<10 OR >40	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Output1 ON

- Based on the image, the temp threshold danger levels is when it reaches 40 or above and 10 or less thus will trigger the device connected to the "Output1" to turn ON
- Thus if an Air-condition unit is connected to "Output1" if the temperature rises above 40 it will turn ON automatically

20.2 Wiring for a control output

Now that we have those configured, for the output wiring, kindly refer to **section 20.1**. If an external relay will be used, refer to the following diagram:




20.3 Geomapping sensors

For a more organized view of your over-all monitoring infrastructure, you could setup the location of each of your Base Units.

From the “Devices” tab, click “Location” to set it up.

Edit Device Location



Drag the marker to improve your search.

Lat: **37.78939560000001** Long: **-122.39186610000002**

After updating it, you could now navigate to the “Map” tab and view the configured devices.



21 Power rating

A Base Unit can be provided with up to 12 watts of power from a PoE source. Because of this, careful power budgeting should be done especially when probes like the IO, QoS, and fuel sensors are to be utilized. Below shows the power ratings of InfraSensing sensor modules:

MODULE	POWER RATING
BASE-5 Base Unit	684 mW
BASE-PRO-6 Base Unit	312 mW
ADDON-LTE LTE/3G/2G Cellular Add-On	2800 mW
ADDON-WIFI Wifi Add-On	720 mW
ADDON-POE 24v/-48v DC Power Add-On (PoE injector)	48v DC via POE; max 22W
ADDON-RTU Modbus RTU (Slave) Add-On	84 mW
EXP-8HUB SensorHub for Base Unit	235 mW
EXP-LWHUB Wireless Hub	720 mW
NODE-LW-1P Wireless Node	720 mW
THIMG-XS Thermal Imaging Sensor (extra small)	492 mW
THIMG-S Thermal Imaging Sensor (small)	492 mW
THIMG-M Thermal Imaging Sensor (medium)	492 mW
THIMG-L Thermal Imaging Sensor (Large)	492 mW
THIMG-CS Thermal Imaging Sensor (CS)	492 mW
THIMG-IRSPOT Infrared Spot Temperature Sensor	60 mW
ENV-THUM Temperature and Humidity Sensor	60 mW
ENV-TEMP Temperature Sensor	60 mW
ENV-TSURFACE Industrial Surface Temperature Sensor	60 mW
ENV-TSTAIN Steel Temperature Sensor	60 mW
ENV-TULTRA Ultra Low Temperature Sensor	60 mW
ENV-TEMP-MAGNET Temperature Magnet Sensor	120 mW
ENV-LHD Linear Heat Trace Sensor	468 mW
DAISY-STARTER Daisy Chain Sensor Start Unit	288 mW
DAISY-BOOSTER Daisy Chain Booster	300 mW
DAISY-THUM Daisy Chain Temp & Humidity Unit	120 mW
DAISY-TEMP Daisy Chain Temperature Sensor Unit	120 mW
DAISY-IRSPOT Daisy Chain IR Spot Temperature Sensor	60 mW
DAISY-TEMP-MAGNET Daisy Chain Temperature Magnet Sensor	120 mW
ENV-NOISE Digital sound & noise level (dbA) sensor	312 mW
ENV-AIRFLW Digital Airflow Sensor	84 mW
ENV-AIRPRESSURE Differential Air Pressure Sensor	96 mW
ENV-PARTICLE Particle Sensor	156 mW
ENV-CORROSION Atmospheric Corrosion (ACM) Sensor	260 mW
ENV-DUST Optical Dust Particle Sensor	156 mW
ENV-LEAK OPTICAL Optical Oil & Hydrocarbon Leak Sensor	2.1 W
ENV-FLEAK-COMBO Fuel Leak Detection Sensor	264 mW
ENV-WLEAK-LOC-COMBO5 Water Leak Location Sensor	264 mW
ENV-WLEAK-COMBO Water Detection & Flooding Sensor	264 mW
ENV-WSPOT Water Spot Sensor	288 mW
GAS-NH3 Ammonia Gas Sensor	1152 mW
GAS-CO2-NDIR Carbon Dioxide NDIR Gas Sensor	1152 mW
GAS-CO Carbon Monoxide Gas Sensor	216 mW
GAS-CL2 Chlorine Gas Sensor	216 mW

MODULE	POWER RATING
GAS-C2H4 Ethylene Gas Sensor	216 mW
GAS-ETO Ethylene Oxide Gas Sensor	216 mW
GAS-CH2O Formaldehyde Gas Sensor	216 mW
GAS-H2-2 Hydrogen Gas Sensor	216 mW
GAS-HCL Hydrogen Chloride Gas Sensor	216 mW
GAS-HF Hydrogen Fluoride Gas Sensor	216 mW
GAS-H2S Hydrogen Sulfide Gas Sensor	216 mW
GAS-CH4 Methane Gas Sensor	216 mW
GAS-CH3SH Methyl Mercaptan Gas Sensor	300 mW
GAS-NO Nitric Oxide Gas Sensor	216 mW
GAS-NO2 Nitrogen Dioxide Gas Sensor	216 mW
GAS-O2 Oxygen Gas Sensor	216 mW
GAS-O3 Ozone Gas Sensor	216 mW
GAS-PH3 Phosphine Gas Sensor	216 mW
GAS-SO2 Sulfur Dioxide Gas Sensor	216 mW
GAS-SF6 Sulfur Hexafluoride Gas Sensor	1240mW
GAS-A1 Refrigerant A1 Gas Sensor	600 mW
GAS-A2L Refrigerant A2L Gas Sensor	600 mW
GAS-A3 Refrigerant A3 Gas Sensor	600 mW
GAS-R-134a Refrigerants R-134a Gas Sensor	1200 mW
PWR-AC-FAIL AC Power Failure Sensor	216 mW
PWR-DC-VOLT DC Voltage Sensor	530 mW
PWR-AC-QUAL AC Power Quality Sensor	460 mW
PWR-AC-CUR AC Current (Power Usage) Sensor	384 mW
PWR-FUEL Ultrasonic Fuel Level Sensor	1008 mW
PWR-GROUND Grounding Sensor	456mW
PWR-BAT-STRING Battery Monitoring - Control Module	500 mW
PWR-BAT-CELL Battery Monitoring - Battery Module	500 mW
SEC-DOOR Door Contact Sensor	240mW
SEC-SHOCK Digital Shock / Vibration Sensor	156mW
SEC-LUX Light Sensor	83mW
SEC-SMOKE Smoke Sensor	240mW
SEC-TILT Tilt Sensor	240mW
SEC-MOTION Motion Sensor	252mW
SEC-SOUND Noise triggered security sensor	144mW
IND-IO IO-Dry Contact Sensor	516mW
IND-0-10V Industrial 0-10V	660 mW

With the given power ratings, for best practices, the fuel sensor, power meter sensor probes, QoS probe and the wireless hub should be connected to a dedicated Base Unit as they are more resource intensive in power and memory than the other ones. Know, however, that in the mentioned list, it would be completely fine to use 2 of them in combination on a single Base Unit (i.e. Base Unit with IO and QoS probes).

22 RMA / Repair

Defective InfraSensing hardware can be returned to one of our repair centers through our Return Merchandise Authorization (RMA) program.

RMA requests have to be submitted through your [order page](#) or from your my.infrasensing.com account.

If purchased from a reseller, add your products to your my.infrasensing.com account.

Customers with an InfraSensing+ agreement enjoy express warranty service for their warranty covered defects.

Warranty covered repairs:

All InfraSensing products are covered by a limited 1 year world-wide warranty as detailed [here](#). If the defect to your product(s) is covered by the warranty, then the product(s) will be diagnosed, repaired or replaced and finally tested before returning the product(s) to you. If the defect is found to be not warranty covered, then an inspection fee of \$75 per product will be invoiced. After payment reception of the inspection fee you have 3 options: receive the defective product(s) back, have it repaired (if repairable) or purchase of a new product(s). In the event of a repair or purchase of new product(s), the cost will be discounted with the paid inspection fee.

Out of warranty repairs:

Do you have a defective device outside of its warranty period or is the defect not covered by warranty? It might still be possible to repair it. In such an event, you can also apply for an out of warranty repair. This incurs an inspection fee of \$75. After receiving payment for the inspection fee, the RMA will be issued to you. If the device can be repaired, then you will receive a quote for repair with a discount for the paid inspection fee. You may also opt for the purchase of a new unit with a discount for the paid inspection fee.

Depending on the complexity of the defects and availability of parts, you should expect a turn-around time of 2 to 5 weeks. We appreciate your patience while we try to repair the defective units.